# Brocade 5600 vRouter Basic Routing

# **Reference Guide**

Supporting Brocade 5600 vRouter 3.5R6



#### © 2015, Brocade Communications Systems, Inc. All Rights Reserved.

ADX, Brocade, Brocade Assurance, the B-wing symbol, DCX, Fabric OS, HyperEdge, ICX, MLX, MyBrocade, OpenScript, The Effortless Network, VCS, VDX, Vplane, and Vyatta are registered trademarks, and Fabric Vision and vADX are trademarks of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of others.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. assume no liability or responsibility to any person or entity with respect to the accuracy of this document or any loss, cost, liability, or damages arising from the information contained herein or the computer programs that accompany it.

The product described by this document may contain open source software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <a href="http://www.brocade.com/support/oscd">http://www.brocade.com/support/oscd</a>.

# **Contents**

Preface		7
	Document conventions	7
	Text formatting conventions	7
	Command syntax conventions	
	Notes, cautions, and warnings	
	Brocade resources	
	Contacting Brocade Technical Support	
	Document feedback	
	Document recuback	
<b>About This Guid</b>	le	11
Earwarding and	Routing Commands	10
i viwaiullig allu		
	clear ip prefix-list	
	clear ipv6 prefix-list	16
	monitor command <traceroute-command></traceroute-command>	
	ping <host></host>	
	ping <host> adaptive <option></option></host>	
	ping <host> allow-broadcast <option></option></host>	
	ping <host> audible <option></option></host>	
	ping <host> bypass-route <option></option></host>	
	ping <host> count <option></option></host>	
	ping <host> deadline <seconds> <option></option></seconds></host>	
	ping <host> ether-size <bytes> <option></option></bytes></host>	
	ping <host> flood <option></option></host>	
	ping <host> interface <host> <option></option></host></host>	
	ping <host> interval <seconds> <option></option></seconds></host>	
	ping <host> mark <fwmark> <option></option></fwmark></host>	
	ping <host> mtu-discovery &lt; do   dont   want &gt; <option></option></host>	
	ping <host> no-loopback <option></option></host>	44
	ping <host> numeric <option></option></host>	46
	ping <host> pattern <hexadecimal-digit> <option></option></hexadecimal-digit></host>	
	ping <host> quiet <option></option></host>	
	ping <host> record-route <option></option></host>	
	ping <host> size <bytes> <option></option></bytes></host>	
	ping <host> tos <number> <option></option></number></host>	
	ping <host> ttl <seconds> <option></option></seconds></host>	
	ping <host> verbose <option></option></host>	
	protocols nsm log	
	protocols nsm log ha	
	reset ip route kernel	
	reset ipv6 route kernel	
	resources group address-group <group-name></group-name>	
	resources group port-group <group-name></group-name>	
	show ip forwarding	
	show ip route	
	show ip route <ipv4net> longer-prefixes</ipv4net>	
	show ip route connected	
	show ip route connectedshow ip route forward	
	OLIO 11 ID TOULO TOL WULU	

	show ip route kernel	
	show ip route static	75
	show ip route summary	76
	show ip route supernets-only	77
	show ip route table	78
	show ipv6 route	79
	show ipv6 route <ipv6net> longer-prefixes</ipv6net>	80
	show ipv6 route bgp	81
	show ipv6 route connected	82
	show ipv6 route forward	83
	show ipv6 route kernel	84
	show ipv6 route ripng	85
	show ipv6 route static	86
	show monitoring protocols rib	87
	traceroute <host> as-path</host>	88
	traceroute <host> bypass-routing</host>	
	traceroute <host> debug-socket</host>	
	traceroute <host> first-ttl <value></value></host>	94
	traceroute <host> gateway <address></address></host>	96
	traceroute <host> icmp-echo</host>	98
	traceroute <host> icmp-extensions</host>	
	traceroute <host> interface <value></value></host>	102
	traceroute <host> max-ttl <value></value></host>	104
	traceroute <host> interval <value></value></host>	106
	traceroute <host> max-ttl <value></value></host>	
	traceroute <host> no-fragment</host>	
	traceroute <host> num-queries <num></num></host>	112
	traceroute <host> port <number></number></host>	
	traceroute <host> seq-queries <number></number></host>	
	traceroute <host> source-addr <host></host></host>	118
	traceroute <host> tcp-syn</host>	
	traceroute <host> tos <value></value></host>	122
	traceroute <host> version</host>	
	traceroute <host> wait-time <value></value></host>	
	traceroute <protocol> <host></host></protocol>	
	traceroute < host>	
ECMP		. 131
	ECMP overview	131
ECMP Command	S	. 133
	protocols ecmp disable	134
	protocols ecmp maximum-paths	135
	protocols ecmp mode <mode></mode>	
	show dataplane route	
	show dataplane route6	
	·	
Static Routes		. 139
	Static route configuration	
	Static routes overview	
	Configuring static routes	139
	Creating floating static routes	140
	Showing static routes in the routing table	
	Static IPv6 route configuration	
	Verify that IPv6 forwarding is enabled	
	•	

	Add the default IPv6 route	142
	Add a static IPv6 route	
	Confirm connectivity	143
Static Route Com	mands	. 145
	protocols static interface-route <subnet> next-hop-interface <interface></interface></subnet>	
	protocols static interface-route6 <subnet> next-hop-interface <interface></interface></subnet>	
	protocols static route <subnet> blackhole <distance></distance></subnet>	
	protocols static route <subnet> next-hop <address></address></subnet>	149
	protocols static route6 <subnet> blackhole</subnet>	
	protocols static route6 <subnet> next-hop <address></address></subnet>	
	protocols static table  interface-route <subnet> next-hop-</subnet>	
	interface <interface></interface>	152
	protocols static table  route <subnet> blackhole <distance></distance></subnet>	. 153
	protocols static table  route <subnet> next-hop <address></address></subnet>	154
	protocols static table  route6 <subnet> next-hop <address></address></subnet>	155
	protocols static table  route6 <subnet> blackhole [distance]</subnet>	156
Source Routes		. 157
	Source routing example	
list of Acronyms		161

## **Preface**

Document conventions	7
Brocade resources.	g
Contacting Brocade Technical Support	g
Document feedback	

## **Document conventions**

The document conventions describe text formatting conventions, command syntax conventions, and important notice formats used in Brocade technical documentation.

## **Text formatting conventions**

Text formatting conventions such as boldface, italic, or Courier font may be used in the flow of the text to highlight specific words or phrases.

Format	Description
bold text	Identifies command names
	Identifies keywords and operands
	Identifies the names of user-manipulated GUI elements
	Identifies text to enter at the GUI
italic text	Identifies emphasis
	Identifies variables
	Identifies document titles
Courier font	Identifies CLI output Identifies command syntax examples

## **Command syntax conventions**

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
bold text	Identifies command names, keywords, and command options.
italic text	Identifies a variable.
value	In Fibre Channel products, a fixed value provided as input to a command option is printed in plain text, for example,show WWN.

Convention	Description
[]	Syntax components displayed within square brackets are optional.
	Default responses to system prompts are enclosed in square brackets.
{ x   y   z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
	In Fibre Channel products, square brackets may be used instead for this purpose.
x   y	A vertical bar separates mutually exclusive elements.
<>	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
	Repeat the previous element, for example, <code>member[member]</code> .
\	Indicates a "soft" line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

## Notes, cautions, and warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

#### NOTE

A Note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

#### **ATTENTION**

An Attention statement indicates a stronger note, for example, to alert you when traffic might be interrupted or the device might reboot.



#### CAUTION

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



#### **DANGER**

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

## **Brocade resources**

Visit the Brocade website to locate related documentation for your product and additional Brocade resources.

You can download additional publications supporting your product at <a href="www.brocade.com">www.brocade.com</a>. Select the Brocade Products tab to locate your product, then click the Brocade product name or image to open the individual product page. The user manuals are available in the resources module at the bottom of the page under the Documentation category.

To get up-to-the-minute information on Brocade products and resources, go to MyBrocade. You can register at no cost to obtain a user ID and password.

Release notes are available on MyBrocade under Product Downloads.

White papers, online demonstrations, and data sheets are available through the Brocade website.

## **Contacting Brocade Technical Support**

As a Brocade customer, you can contact Brocade Technical Support 24x7 online, by telephone, or by e-mail. Brocade OEM customers contact their OEM/Solutions provider.

#### **Brocade customers**

For product support information and the latest information on contacting the Technical Assistance Center, go to http://www.brocade.com/services-support/index.html.

If you have purchased Brocade product support directly from Brocade, use one of the following methods to contact the Brocade Technical Assistance Center 24x7.

Online	Telephone	E-mail
Preferred method of contact for non-urgent issues:	Required for Sev 1-Critical and Sev 2-High issues:	support@brocade.com Please include:
<ul> <li>My Cases through MyBrocade</li> <li>Software downloads and licensing tools</li> <li>Knowledge Base</li> </ul>	<ul> <li>Continental US: 1-800-752-8061</li> <li>Europe, Middle East, Africa, and Asia Pacific: +800-AT FIBREE (+800 28 34 27 33)</li> <li>For areas unable to access toll free number: +1-408-333-6061</li> <li>Toll-free numbers are available in many countries.</li> </ul>	<ul> <li>Problem summary</li> <li>Serial number</li> <li>Installation details</li> <li>Environment description</li> </ul>

### **Brocade OEM customers**

If you have purchased Brocade product support from a Brocade OEM/Solution Provider, contact your OEM/Solution Provider for all of your product support needs.

- OEM/Solution Providers are trained and certified by Brocade to support Brocade® products.
- Brocade provides backline support for issues that cannot be resolved by the OEM/Solution Provider.

- Brocade Supplemental Support augments your existing OEM support contract, providing direct access to Brocade expertise. For more information, contact Brocade or your OEM.
- For questions regarding service levels and response times, contact your OEM/Solution Provider.

## **Document feedback**

To send feedback and report errors in the documentation you can use the feedback form posted with the document or you can e-mail the documentation team.

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. You can provide feedback in two ways:

- Through the online feedback form in the HTML documents posted on www.brocade.com.
- By sending your feedback to documentation@brocade.com.

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

# **About This Guide**

This guide describes information about forwarding and routing on the Brocade 5600 vRouter (referred to as a virtual router, vRouter, or router in the guide).

About This Guide

# **Forwarding and Routing Commands**

clear ip prefix-list	15
clear ipv6 prefix-list	16
monitor command <traceroute-command></traceroute-command>	17
• ping <host></host>	18
• ping <host> adaptive <option></option></host>	19
• ping <host> allow-broadcast <option></option></host>	22
• ping <host> audible <option></option></host>	24
• ping <host> bypass-route <option></option></host>	26
• ping <host> count <option></option></host>	28
• ping <host> deadline <seconds> <option></option></seconds></host>	30
• ping <host> ether-size <bytes> <option></option></bytes></host>	32
• ping <host> flood <option></option></host>	34
• ping <host> interface <host> <option></option></host></host>	36
• ping <host> interval <seconds> <option></option></seconds></host>	38
• ping <host> mark <fwmark> <option></option></fwmark></host>	40
• ping <host> mtu-discovery &lt; do   dont   want &gt; <option></option></host>	42
• ping <host> no-loopback <option></option></host>	44
• ping <host> numeric <option></option></host>	46
• ping <host> pattern <hexadecimal-digit> <option></option></hexadecimal-digit></host>	48
• ping <host> quiet <option></option></host>	50
• ping <host> record-route <option></option></host>	52
• ping <host> size <bytes> <option></option></bytes></host>	54
• ping <host> tos <number> <option></option></number></host>	56
• ping <host> ttl <seconds> <option></option></seconds></host>	58
• ping <host> verbose <option></option></host>	60
protocols nsm log	62
protocols nsm log ha	63
reset ip route kernel	64
• reset ipv6 route kernel	65
• resources group address-group <group-name></group-name>	66
• resources group port-group <group-name></group-name>	67
show ip forwarding.	69
• show ip route	
• show ip route <ipv4net> longer-prefixes</ipv4net>	
show ip route connected	
show ip route forward	
show ip route kernel	
show ip route static	
show ip route summary	
show ip route supernets-only	
show ip route table	
• show ipv6 route	
• show ipv6 route <ipv6net> longer-prefixes</ipv6net>	80

show ipv6 route bgp	81
show ipv6 route connected	82
show ipv6 route forward	83
show ipv6 route kernel	84
show ipv6 route ripng	85
show ipv6 route static	86
show monitoring protocols rib	87
traceroute <host> as-path</host>	88
traceroute <host> bypass-routing</host>	90
traceroute <host> debug-socket</host>	92
traceroute <host> first-ttl <value></value></host>	94
traceroute <host> gateway <address></address></host>	96
traceroute <host> icmp-echo</host>	98
traceroute <host> icmp-extensions</host>	100
traceroute <host> interface <value></value></host>	102
traceroute <host> max-ttl <value></value></host>	104
traceroute <host> interval <value></value></host>	106
traceroute <host> max-ttl <value></value></host>	108
traceroute <host> no-fragment</host>	110
traceroute <host> num-queries <num></num></host>	112
traceroute <host> port <number></number></host>	114
traceroute <host> seq-queries <number></number></host>	116
traceroute <host> source-addr <host></host></host>	118
traceroute <host> tcp-syn</host>	120
traceroute <host> tos <value></value></host>	122
traceroute <host> version</host>	124
traceroute <host> wait-time <value></value></host>	126
traceroute <protocol> <host></host></protocol>	128
• traceroute <host></host>	120

# clear ip prefix-list

Clears statistics for or the status of a prefix list.

Syntax clear ip prefix-list [ list-name [ ipv4net ] ]

Command Default Statistics for or the status of all prefix lists is cleared.

Parameters list-name

Optional. A prefix list.

ipv4net

Optional. A network.

Modes Operational mode

# clear ipv6 prefix-list

Clears statistics for or the status of an IPv6 prefix list.

Syntax clear ipv6 prefix-list [ list-name [ ipv6net ] ]

Command Default Statistics for or the status of all IPv6 prefix lists is cleared.

Parameters list-name

Optional. An IPv6 prefix list.

ipv6net

Optional. An IPv6 network.

Modes Operational mode

## monitor command < traceroute-command >

Monitors a traceroute command.

Syntax monitor command traceroute-command

run monitor command traceroute-command

Parameters traceroute-command

The traceroute command to be monitored. The traceroute command must be

enclosed in quotation marks.

Modes Operational mode

Configuration mode

Usage Guidelines Use this command to display the output of a traceroute command. The display information is refreshed

every two seconds.

Use the **run** form of this command in configuration mode.

## ping <host>

Sends Internet Control Message Protocol (ICMP) ECHO\_REQUEST packets to a network host.

Syntax ping { ipv4\_address | ipv6\_address | hostname }

Parameters ipv4\_address

Pings the IPv4 address of the host.

ipv6\_address

Pings the IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

Modes Operational mode

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When using the **ping** command for fault isolation, enter the command on the local host to verify that the local network interface is up and running. Then, ping hosts and gateways farther away. Round-trip times and packet-loss statistics are computed.

If duplicate packets are received, they are not included in the packet-loss calculation, although the round-trip time of these packets is used in calculating the minimum, average, and maximum round-trip times.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether the network host, www.google.com is reachable.

```
\label{eq:vyatta@VR-2:/etc$ ping www.google.com} $$\operatorname{PING www.google.com}$ (216.58.196.100) 56(84) bytes of data. $$64 bytes from maa03s19-in-f4.1e100.net (216.58.196.100): icmp_req=1 ttl=54 time=42.3 ms $$^{C}$ --- www.google.com ping statistics --- 1 packets transmitted, 1 received, 0% packet loss, time 0ms rtt min/avg/max/mdev = 42.364/42.364/42.364/0.000 ms $$$$
```

## ping <host> adaptive <option>

Sets the interpacket interval adaptively such that the interpacket interval adjusts to round-trip time.

Syntax ping { ipv4\_address | ipv6\_address | hostname } adaptive option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

adaptive

Sets the interpacket interval adaptively such that the interpacket interval adjusts to round-trip time. The **adaptive** setting ensures that not more than one (or more, if preload is set) unanswered probes are present in the network.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the router pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When using the **ping** command for fault isolation, enter the command on the local host to verify that the local network interface is up and running. Then, ping hosts and gateways farther away. Round-trip times and packet-loss statistics are computed.

If duplicate packets are received, they are not included in the packet-loss calculation, although the round-trip time of these packets is used in calculating the minimum, average, and maximum round-trip times.

#### NOTE

The minimum interpacket interval is 200 ms for all users, except for a super-user.

When the ping command is interrupted by typing <Ctrl>+c , a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether the <a href="www.google.com">www.google.com</a> network is reachable with an interpacket interval. The example also displays the time stamp in the ping output.

```
vyatta@vyatta:\sim$ ping www.google.com adaptive timestamp audible PING www.google.com (216.58.216.164) 56(84) bytes of data.
[1428886179.416698] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp req=2 ttl=54 time=20.0 ms
[1428886179.457896] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp req=4 ttl=54 time=20.0 ms
[1428886179.499170] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp req=6 ttl=54 time=20.2 ms
[14\overline{28}886\overline{179.539836}] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp_req=8 ttl=54 time=19.9 ms
[142886179.580788] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp req=10 ttl=54 time=19.9 ms
[14\overline{28}886\overline{179.621507}] 64 bytes from seal5s02-in-f4.1e100.net (216.58.216.164): icmp_req=12 ttl=54 time=20.0 ms
[14\overline{28}886\overline{179.662363}] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp req=14 ttl=54 time=19.8 ms
[1428886179.703528] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp_req=16 ttl=54 time=20.1 ms
[1428886179.744554] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp_req=18 ttl=54 time=20.0 ms
[1428886179.785702] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp req=20 ttl=54 time=20.1 ms
[1428886179.826861] 64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164):
icmp req=22 ttl=54 time=20.2 ms
[1428886181.384621] From 10.18.170.201 icmp_seq=1 Destination Host Unreachable [1428886181.385770] From 10.18.170.201 icmp_seq=3 Destination Host Unreachable
[1428886181.386512] From 10.18.170.201 icmp_seq=5 Destination Host Unreachable
[1428886181.387046] From 10.18.170.201 icmp_seq=7 Destination Host Unreachable [1428886181.387599] From 10.18.170.201 icmp_seq=9 Destination Host Unreachable
[1428886181.388177] From 10.18.170.201 icmp_seq=11 Destination Host Unreachable [1428886181.388707] From 10.18.170.201 icmp_seq=13 Destination Host Unreachable [1428886181.389269] From 10.18.170.201 icmp_seq=15 Destination Host Unreachable
[1428886181.389865] From 10.18.170.201 icmp_seq=17 Destination Host Unreachable
[1428886181.390681] From 10.18.170.201 icmp_seq=19 Destination Host Unreachable [1428886181.391494] From 10.18.170.201 icmp_seq=21 Destination Host Unreachable
[216.164): icmp req=165 ttl=54 time=20.4 ms
```

## ping <host> allow-broadcast <option>

Allows the pinging of a broadcast address.

Syntax ping { ipv4\_address | ipv6\_address | hostname } allow-broadcast option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

allow-broadcast

Allows pinging a broadcast address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the router pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies the interface that the device must use as source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode.

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When using the **ping** command for fault isolation, enter the command on the local host to verify that the local network interface is up and running. Then, ping hosts and gateways farther away. Round-trip times and packet-loss statistics are computed.

If duplicate packets are received, they are not included in the packet-loss calculation, although the round-trip time of these packets is used in calculating the minimum, average, and maximum round-trip times.

When the **ping** command is interrupted by typing <Ctrl>+cs, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether www.google.com network is reachable. It also shows how to allow the pinging of the broadcast address and define a life-time of 30 hops for each host.

## ping <host> audible <option>

Makes a beep sound when the router pings for the host details.

Syntax ping { ipv4\_address | ipv6\_address | hostname } audible option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

audible

Makes a beep sound while the device pings for the host details.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the router pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies the interface that the device must use as source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When using the **ping** command for fault isolation, enter the command on the local host to verify that the local network interface is up and running. Then, ping hosts and gateways farther away. Round-trip times and packet-loss statistics are computed.

If duplicate packets are received, they are not included in the packet-loss calculation, although the round-trip time of these packets is used in calculating the minimum, average, and maximum round-trip times.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### Examples

This example shows how to configure the router to send an ICMP\_ECHO request five times, making a beep sound on every ping.

```
vyatta@vyatta:~$ ping www.google.com audible count 5
PING www.google.com (216.58.216.164) 56(84) bytes of data.
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=2 ttl=54 time=20.0
ms
From 10.18.170.201 icmp_seq=1 Destination Host Unreachable
From 10.18.170.201 icmp_seq=3 Destination Host Unreachable
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=4 ttl=54 time=20.1
ms
--- www.google.com ping statistics ---
5 packets transmitted, 2 received, +2 errors, 60% packet loss, time 4010ms
rtt min/avg/max/mdev = 20.048/20.075/20.103/0.144 ms, pipe 3
vyatta@vyatta:~$
```

## ping <host> bypass-route <option>

Bypasses the normal routing tables and sends a ping request directly to a host on an attached interface.

Syntax ping { ipv4\_address | ipv6\_address | hostname } bypass-route option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

bypass-route

Bypasses the normal routing tables and sends directly to a host on an attached

interface. If the host is not directly attached to a network, an error is returned.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the router pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

If the host is not directly attached to a network, an error is returned.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to bypass the normal routing tables and send a ping request directly to a host on an attached interface.

```
vyatta@vyatta:~$ ping www.google.com bypass-route
PING www.google.com (216.58.216.164) 56(84) bytes of data.
ping: sendmsg: Network is unreachable
```

## ping <host> count <option>

Specifies a number of ping requests that the router must send.

Syntax ping { ipv4\_address | ipv6\_address | hostname } count numberoption

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

number

The number of ping requests to send.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound, while the router pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Supress loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode.

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether <a href="www.google.com">www.google.com</a> network is reachable by sending five ICMP\_ECHO requests and that the router waits for five reply packets for ten seconds.

```
vyatta@vyatta:~$ ping www.google.com count 5 deadline 10
PING www.google.com (216.58.216.164) 56(84) bytes of data.
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=2 ttl=54 time=20.0
ms
From 10.18.170.201 icmp_seq=1 Destination Host Unreachable
From 10.18.170.201 icmp seq=3 Destination Host Unreachable
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=4 ttl=54 time=20.1
ms
--- www.google.com ping statistics ---
5 packets transmitted, 2 received, +2 errors, 60% packet loss, time 4010ms
rtt min/avg/max/mdev = 20.048/20.075/20.103/0.144 ms, pipe 3
vyatta@vyatta:~$ ping www.google.com count 5
```

# ping <host> deadline <seconds> <option>

Specifies the number of seconds before which the ping expires.

Syntax ping { ipv4\_address | ipv6\_address | hostname } deadline seconds option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

seconds

The number of seconds before which ping exits.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the router pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

#### **Usage Guidelines**

The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether www.google.com network is reachable within three seconds.

```
vyatta@vyatta:~$ ping www.google.com deadline 3
PING www.google.com (216.58.216.164) 56(84) bytes of data.
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=1 ttl=54 time=19.8
ms
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=3 ttl=54 time=20.1
ms
--- www.google.com ping statistics ---
3 packets transmitted, 2 received, 33% packet loss, time 2004ms
rtt min/avg/max/mdev = 19.873/19.995/20.118/0.187 ms
```

## ping <host> ether-size <bytes> <option>

Matches the overall size of the data packet with the resultant size of the Layer 3 packet.

Syntax ping { ipv4\_address | ipv6\_address | hostname } ether-size bytes option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

bytes

The number of bytes.

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound during every ping, while the router pings for host

details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies the interface that the device must use as source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

Usage Guidelines Th

The **ping** command tests whether a network host is reachable.

The **ping** command when used with the ether-size option specifies the size of the resultant Layer 3 packet, such as ICMP data plus ICMP headers, IP headers, and so on.

The **ping** *host* **ether-size** command ensures that the resultant size supports Layer 3 IP packet size. The Ethernet MTU is 1,500 bytes. Therefore, the **ping** *host* **ether-size** command subtracts 28 bytes from the host size of the Layer 3 packet to ensure that the resultant value matches the overall size of the data packet. The **ping** *host* **ether-size** command avoids the fragmentation overhead due to the MTU.

#### **NOTE**

You can use either the **ping** *host* **size** or **ping** *host* **ether-size** command to ping a host network. You cannot use both commands simultaneously.

## ping <host> flood <option>

Sends 100 ping requests each second.

Syntax ping { ipv4\_address | ipv6\_address | hostname } flood option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes noise while the device pings for the host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies the interface that the device must use as source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

#### Usage Guidelines

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether www.google.com network is reachable by sending a maximum of 100 ping requests each second.

## ping <host> interface <host> <option>

Specifies an interface that the device must use as the source address.

Syntax ping { ipv4\_addres | ipv6\_address | hostname } interface { ipv4\_addres | ipv6\_address | hostname }

option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

Use the **ping** host **interface** command when pinging IPv6 link-local address.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether an IPv4 interface is reachable.

```
vyatta@VR-1:~$ ping 192.1.2.2 interface dp0s6
PING 192.1.2.2 (192.1.2.2) from 192.1.2.1 dp0s6: 56(84) bytes of data.
64 bytes from 192.1.2.2: icmp_req=1 tt1=64 time=1.66 ms
^C
--- 192.1.2.2 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 0ms
rtt min/avg/max/mdev = 1.664/1.664/1.664/0.000 ms
vyatta@VR-1:~$ ping 192.1.2.2 interface 192.1.2.1
PING 192.1.2.2 (192.1.2.2) from 192.1.2.1: 56(84) bytes of data.
64 bytes from 192.1.2.2: icmp_req=1 tt1=64 time=1.02 ms
^C
```

This example shows how to test whether an IPv6 interface is reachable.

```
vyatta@VR-1:~$ ping 2012:dead::2 interface 2012:dead::1
PING 2012:dead::2(2012:dead::2) from 2012:dead::1 : 56 data bytes
64 bytes from 2012:dead::2: icmp_seq=1 ttl=64 time=3.04 ms
64 bytes from 2012:dead::2: icmp_seq=2 ttl=64 time=1.01 ms
^C
--- 2012:dead::2 ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 1001ms
rtt min/avg/max/mdev = 1.012/2.027/3.043/1.016 ms
```

# ping <host> interval <seconds> <option>

Specifies the time in seconds for which the device must wait between ping requests.

Syntax ping { ipv4\_address | ipv6\_address | hostname } interval secondsoption

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

seconds

The number of seconds for which the device must wait between ping requests.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test whether www.google.com network is reachable by providing 3 seconds of time between 5 ping attempts.

```
vyatta@vyatta:~$ ping www.google.com interval 3 count 15
PING www.google.com (216.58.216.164) 56(84) bytes of data.
64 bytes from sea15s02-in-f4.1e100.net (216.58.216.164): icmp_req=1 ttl=54 time=20.2
ms
From 10.18.170.201 icmp_seq=2 Destination Host Unreachable
From 10.18.170.201 icmp_seq=3 Destination Host Unreachable
From 10.18.170.201 icmp_seq=4 Destination Host Unreachable
From 10.18.170.201 icmp_seq=5 Destination Host Unreachable
From 10.18.170.201 icmp_seq=6 Destination Host Unreachable
From 10.18.170.201 icmp_seq=7 Destination Host Unreachable
From 10.18.170.201 icmp_seq=8 Destination Host Unreachable
From 10.18.170.201 icmp_seq=9 Destination Host Unreachable
From 10.18.170.201 icmp_seq=10 Destination Host Unreachable
From 10.18.170.201 icmp_seq=11 Destination Host Unreachable
From 10.18.170.201 icmp_seq=12 Destination Host Unreachable
From 10.18.170.201 icmp_seq=13 Destination Host Unreachable
From 10.18.170.201 icmp_seq=14 Destination Host Unreachable
From 10.18.170.201 icmp_seq=15 Destination Host Unreachable
From 10.18.170.201 icmp_seq=16 Destination Host Unreachable
From 10.18.170.201 icmp_seq=16 Destination Ho
```

# ping <host> mark <fwmark> <option>

Specifies that the device must consider the ping request for special processing.

Syntax ping { ipv4\_address | ipv6\_address | hostname } mark fwmark option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

fwmark

Marks the outgoing packet.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

**Usage Guidelines** The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

The **ping** host **mark** fwmark command is used in usecases within the operating system. For example, to tag the outgoing packets while configuring policy routing, to select specific outbound processing.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

# ping <host> mtu-discovery < do | dont | want > <option>

Selects the discovery strategy of the path maximum transmission unit (PMTU).

Syntax ping { ipv4\_address | ipv6\_address | hostname } mtu-discovery { do | dont | want } option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

do

Prohibits fragmentation, even for the local packet. Sets a do-not fragment (DF)

flag to the router.

want

Performs a PMTU discovery. During the discovery the device fragments the

packet locally.

dont

Prohibits fragmentation, but does not set a DF flag.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The **ping** host **mtu-discovery** command selects the discovery strategy of the PMTU, based on the parameters provided. The command checks the size of the packet. If the size is equal to or greater than the maximum data payload that is available in a packet, the device determines whether the packet has to be fragmented, based on the discovery strategy of the PMTU.

#### **Examples**

This example shows how to test 1472 bytes of data of the host 10.0.0.103 for network reachability while prohibiting network fragmentation during the ping. However a do-not-fragment flag is set for the router.

```
vyatta@VR-1:~$ ping 10.0.0.103 size 1472 mtu-discovery do PING 10.0.0.103 (10.0.0.103) 1472(1500) bytes of data. 1480 bytes from 10.0.0.103: icmp_req=1 ttl=64 time=0.923 ms ^[R14480 bytes from 10.0.0.103: icmp_req=2 ttl=64 time=1.35 ms ^C --- 10.0.0.103 ping statistics --- 2 packets transmitted, 2 received, 0% packet loss, time 999ms rtt min/avg/max/mdev = 0.923/1.137/1.352/0.217 ms
```

This example shows how to test 1472 bytes of data of the host 10.0.0.103 for network reachability while prohibiting network fragmentation during the ping. However a do-not-fragment flag is not set for the router.

```
vyatta@VR-1:~$ ping 10.0.0.103 size 1472 mtu-discovery dont PING 10.0.0.103 (10.0.0.103) 1472 (1500) bytes of data. 1480 bytes from 10.0.0.103: icmp_req=1 ttl=64 time=1.25 ms ^{\circ}\text{C} --- 10.0.0.103 ping statistics --- 1 packets transmitted, 1 received, 0% packet loss, time 0ms rtt min/avg/max/mdev = 1.250/1.250/1.250/0.000 ms
```

This example shows how to perform a discovery strategy for PMTU during a ping request. During the discovery, the router fragments the packet locally.

```
vyatta@VR-1:~$ ping 10.0.0.103 size 1472 mtu-discovery want PING 10.0.0.103 (10.0.0.103) 1472 (1500) bytes of data. 1480 bytes from 10.0.0.103: icmp_req=1 ttl=64 time=1.00 ms ^C --- 10.0.0.103 ping statistics --- 1 packets transmitted, 1 received, 0% packet loss, time 0ms rtt min/avg/max/mdev = 1.005/1.005/1.005/0.000 ms
```

# ping <host> no-loopback <option>

Suppresses loopback of multicast pings.

Syntax ping { ipv4\_address | ipv6\_address | hostname} no-loopback option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes noise while the device pings for the host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

**Usage Guidelines** The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the **ping** command is interrupted by typing <Ctrl>+c , a brief statistical summary is displayed.

# ping <host> numeric <option>

Specifies that the router must not resolve domain name system (DNS) names during a ping.

Syntax ping { ipv4\_address | ipv6\_address | hostname } numeric option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

numeric

The number of ping requests to send.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

Usage Guidelines The ping command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

**Examples** 

This example shows how to ensure that a ping command provides only numeric output, which means that the router does not look up symbolic names for host addresses.

```
vyatta@VR-2:/etc$ ping www.google.com numeric.
PING www.google.com (216.58.196.100) 56(84) bytes of data.
64 bytes from 216.58.196.100: icmp_req=1 ttl=54 time=42.1 ms
64 bytes from 216.58.196.100: icmp_req=2 ttl=54 time=44.3 ms
^C
--- www.google.com ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 1001ms
rtt min/avg/max/mdev = 42.177/43.278/44.379/1.101 ms
```

# ping <host> pattern <hexadecimal-digit> <option>

Specifies a hexadecimal digit pattern to fill the packet.

Syntax ping { ipv4\_addres | ipv6\_address | hostname } pattern hexadecimal-digit option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

hexadecimal-digit

Hexadecimal digit to fill the packet.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies the interface that the device must use as source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to send a packet that contains all 1's. This example helps to diagnose datadependent problems in a network.

```
vyatta@vyatta:~$ ping www.google.com pattern BCD
PATTERN: 0xbc0d
PING www.google.com (173.194.33.176) 56(84) bytes of data.
64 bytes from sea09s18-in-f16.1e100.net (173.194.33.176): icmp_req=1 ttl=54 time=20.4
ms
64 bytes from sea09s18-in-f16.1e100.net (173.194.33.176): icmp_req=3 ttl=54 time=20.3
ms
From 10.18.170.201 icmp_seq=2 Destination Host Unreachable
From 10.18.170.201 icmp_seq=4 Destination Host Unreachable
--- www.google.com ping statistics ---
205 packets transmitted, 103 received, +102 errors, 49% packet loss, time 204233ms
rtt min/avg/max/mdev = 20.095/20.417/20.861/0.235 ms, pipe 4
vyatta@vyatta:~$ ^C
vyatta@vyatta:~$
```

## ping <host> quiet <option>

Prints only the ping summary page.

Syntax ping { ipv4\_address | ipv6\_address | hostname } quiet option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for host details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

**Usage Guidelines** The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

**Examples** This example shows how to print only the ping summary page for www.google.com.

vyatta@vyatta:~\$ ping www.google.com quiet
--- www.google.com ping statistics --15 packets transmitted, 1 received, +14 errors, 93% packet loss, time 41999ms
rtt min/avg/max/mdev = 20.264/20.264/20.264/0.000 ms

# ping <host> record-route <option>

Records the route that a packet takes.

Syntax ping { ipv4\_address | ipv6\_address | hostname } record-route option

Parameters ipv4\_address

Pings the IPv4 address of the host.

ipv6\_address

Pings the IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound on every ping, while the device pings for the host

details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

**Usage Guidelines** The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

# ping <host> size <bytes> <option>

Specifies the number of bytes to send for a ping request.

Syntax ping { ipv4\_address | ipv6\_address | hostname } size bytes option

Parameters ipv4\_address

Pings the IPv4 address of the host.

ipv6\_address

Pings the IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

bytes

The number of bytes to send for a ping request.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound during every ping, while the device pings for the host

details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the request for special processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

**Usage Guidelines** The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the ping command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

**Examples** 

This example shows how to specify the number of bytes to send while testing the IP address for network reachability.

```
vyatta@VR-1:~$ ping 2012:dead::1 size 1200
PING 2012:dead::1(2012:dead::1) 1200 data bytes
1208 bytes from 2012:dead::1: icmp_seq=1 ttl=64 time=0.046 ms
1208 bytes from 2012:dead::1: icmp_seq=2 ttl=64 time=0.128 ms
^C
--- 2012:dead::1 ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 999ms
rtt min/avg/max/mdev = 0.046/0.087/0.128/0.041 ms
vyatta@VR-1:~$ ping 2012:dead::1
PING 2012:dead::1(2012:dead::1) 56 data bytes
64 bytes from 2012:dead::1: icmp_seq=1 ttl=64 time=0.026 ms
64 bytes from 2012:dead::1: icmp_seq=2 ttl=64 time=0.034 ms
^C
```

# ping <host> tos <number> <option>

Marks a packet with a specified time of service (TOS).

Syntax ping { ipv4\_address | ipv6\_address | hostname } tos number option

Parameters ipv4\_address

Pings the IPv4 address of the host.

ipv6\_address

Pings the IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

number

The tos number.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound during every ping, while the device pings for the host

details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to test a packet for network reachability by defining the time of service as one second.

```
vyatta@VR-1:~$ ping 127.0.0.1 tos 1
PING 127.0.0.1 (127.0.0.1) 56(84) bytes of data.
64 bytes from 127.0.0.1: icmp_req=1 ttl=64 time=0.409 ms
64 bytes from 127.0.0.1: icmp_req=2 ttl=64 time=0.027 ms
^C
--- 127.0.0.1 ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 999ms
rtt min/avg/max/mdev = 0.027/0.218/0.409/0.191 ms
```

# ping <host> ttl <seconds> <option>

Specifies the maximum packet life-time for a host.

Syntax ping { ipv4\_address | ipv6\_address | hostname } ttl seconds option

Parameters ipv4\_address

The IPv4 address of the host.

ipv6\_address

The IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

seconds

The time in milliseconds to specify the maximum packet life-time for a host.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound during every ping, while the device pings for the host

details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer 3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Supress loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

#### Modes Operational mode

#### **Usage Guidelines**

The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

#### **Examples**

This example shows how to specify the maximum packet life-time for a host while testing the host for network reachability. The life-time defined in this example is 200 seconds.

```
vyatta@VR-1:~$ ping 192.1.2.2 ttl 200
PING 192.1.2.2 (192.1.2.2) 56(84) bytes of data.
64 bytes from 192.1.2.2: icmp_req=1 ttl=64 time=1.41 ms
^C
--- 192.1.2.2 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 0ms
rtt min/avg/max/mdev = 1.412/1.412/1.412/0.000 ms
```

## ping <host> verbose <option>

Displays a detailed output for the ping command.

Syntax ping { ipv4\_address | ipv6\_address | hostname } verbose option

Parameters ipv4\_address

Pings the IPv4 address of the host.

ipv6\_address

Pings the IPv6 address of the host.

hostname

A host being pinged. This keyword is used when the host is specified as a host

name rather than as an IP address.

option

Each of the following entries are considered options. These options can be

issued consecutively, that is, in the same command line.

adaptive

Adaptively sets interpacket interval.

allow-broadcast

Allows you to ping broadcast address.

audible

Makes a beep sound during every ping, while the device pings for the host

details.

bypass-route

Bypasses normal routing tables during ping.

count

Specifies the number of ping requests to send.

deadline

Specifies the number of seconds before which ping expires.

ether-size

Matches the overall size of the data packet with the resultant size of the

Layer-3 packet.

flood

Sends 100 ping requests each second.

interface

Specifies an interface that the device must use as the source address.

interval

Specifies the time in seconds for which the device must wait between ping

requests.

mark

Specifies that the device must consider the ping request for special

processing.

mtu-discovery

Specifies the path MTU discovery strategy.

no-loopback

Suppresses loop-back of multicast pings.

numeric

Does not resolve domain name system (DNS) names during ping.

pattern

Specifies the hexadecimal digit pattern to fill the packet.

quiet

Prints only the ping summary page.

record-route

Records the route that the packet takes.

size

Specifies the number of bytes to send for a ping request.

timestamp

Displays the timestamp during ping output.

tos

Marks packet with specified time of service (TOS).

ttl

Specifies the maximum packet life-time for a host.

verbose

Displays a detailed output for the ping command.

Modes Operational mode

**Usage Guidelines** The **ping** command tests whether a network host is reachable.

The **ping** command uses the ECHO\_REQUEST datagram (ping) of the ICMP protocol to get an ICMP ECHO\_RESPONSE from a host or gateway. ECHO\_REQUEST datagrams have an IP and an ICMP header, followed by a *struct timeval* data type and then an arbitrary number of pad bytes that are used to fill the packet.

When the **ping** command is interrupted by typing <Ctrl>+c, a brief statistical summary is displayed.

# protocols nsm log

Enables logging for NSM.

Syntax set protocols nsm { all | events | ha | kernel| packet }

delete protocols nsm { all | events | ha | kernel| packet }

show protocols nsm { all | events | ha | kernel| packet }

Command Default

None

all

Parameters

Enables all NSM logs.

events

Enables only NSM event logs.

ha

Enables only NSM high availability (HA) logs.

kernel

Enables only NSM kernel logs.

packet

Enables only NSM packet logs.

Modes Configuration mode

Configuration Statement

```
protocols {
    nsm {
       log {
            all events
            ha kernel packet
            }
       }
}
```

**Usage Guidelines** 

Use the set form of this command to enable NSM logs.

Use the delete form of this command to remove NSM logs.

Use the **show** form of this command to view NSM logs.

# protocols nsm log ha

```
Enables logging for NSM HA.
```

set protocols nsm ha { all } Syntax

delete protocols nsm ha { all }

show protocols nsm ha { all }

**Command Default** None

**Parameters** 

all

Enables all NSM HA logs

Modes

Configuration mode

Configuration Statement

```
protocols {
     nsm {
      log {
        ha {
all
          }
      }
```

**Usage Guidelines** 

Use the **set** form of this command to enable NSM high availability (HA) logs.

Use the delete form of this command to remove NSM HA logs.

Use the **show** form of this command to view NSM HA logs.

# reset ip route kernel

Clears all the entries from the IP kernel route.

Syntax reset ip route kernel

Modes Operational mode

# reset ipv6 route kernel

Clears all the entries from the IPv6 kernel route.

Syntax reset ipv6 route kernel

Modes Operational mode

### resources group address-group <group-name>

Defines a group of IP addresses that are referenced in firewall rules.

Syntax set resources group address-group group-name { address address | description desc }

delete resources group address-group group-name { address address | description desc }

show resources group address-group group-name { address address | description desc }

#### Parameters address-group

A group of IPv4 addresses or address ranges.

group-name

Mandatory. The name of a firewall address group.

address address

Mandatory. Adds the specified IPv4 address or range of IPv4 addresses to the specified firewall address group. IPv4 address ranges are specified by separating two contiguous IPv4 addresses with a hyphen, for example, 10.0.0.1-10.0.0.50.

description desc

Provides a brief description for the firewall address group.

#### Modes Configuration mode

# Configuration Statement

```
resources {
    group {
       address-group group-name {
            address address
            description desc
       }
       }
}
```

#### **Usage Guidelines**

Use this command to specify an address group. A firewall address group is a collection of host IP addresses and address ranges that, once defined, can be collectively referenced within a firewall command.

A firewall address group is considered matched if the packet address matches any address or address range within the group.

Use the set form of this command to specify the address group.

Use the delete form of this command to remove a firewall address group or its members.

Use the **show** form of this command to view the configuration of a firewall address group.

### resources group port-group <group-name>

Defines a group of ports that are referenced in firewall rules.

#### Syntax

set resources group port-group port-group-name { description description { port [ name | 1-65535 | start - end ] }

**delete resources group port-group** port-group-name { **description** description | **port** [ name | 1-65535 | start - end ] }

**show resources group port-group** *port-group-name* { **description** | **port** *name* | 1-65535 | *start* - *end* **test** ] }

#### **Parameters**

#### port-group port-group-name

Matches the destination port packets against the specified port group. The packet is considered a match if it matches any port name or number specified in the group. Only one port group may be specified. The port group must already be defined. A packet is considered a match for an address, a network, or a port group if it matches any host IP address, network address, or port name or number, respectively, in the group. However, if more than one group is specified, the packet must be a match for both groups in order to be considered a match. For example, if an address group and a port group are both specified, the packet's destination must match at least one item in the address group and at least one item in the port group.

#### description description

Provides a brief description for the network group.

port [ name | 1-65535 | start - end ]

Specifies the port group parameters.

port-name

Matches the name of an IP service; for example, http. You can specify any service name in the file /etc/services.

port-num

Matches a port number. The range is 1 through 65535.

start-end

Matches the specified range of ports; for example, 1001-1005.

#### Modes

#### Configuration mode

#### Configuration Statement

```
resources {
    group {
        port-group group-name {
            port name
            description desc
        }
    }
}
```

#### **Usage Guidelines**

Use this command to define a network group. A network group is a collection of network addresses that, once defined, can be collectively referenced within a firewall command.

A network group is considered matched if the packet address matches any network address or address range within the group.

Use the set form of this command to define a network group.

Use the **delete** form of this command to remove a network group or its members.

Forwarding	and	Routing	Commands
i oiwaiaiiis	ana	1 (Outilie	Oulillianas

68

Use the **show** form of this command to view the configuration of a network group.

# show ip forwarding

Displays IP forwarding status.

Syntax show ip forwarding

Modes Operational mode

**Examples** The following example shows how to display the status of IP forwarding.

vyatta@vyatta:~\$ show ip forwarding
IP forwarding is on
vyatta@vyatta:~\$

### show ip route

Displays routes stored in the Routing Information Base (RIB) and Forwarding Information Base (FIB).

Syntax show ip route [ ipv4 | ipv4net ]

Command Default Lists all routes stored in the RIB and FIB.

Parameters ipv4

Optional. An IP address.

ipv4net

Optional. A prefix.

Modes Operational mode

You can also see the routes shown in the FIB by using show ip route forward on page 73.

**Examples** The following example shows how to display routes stored in the RIB and FIB.

```
vyatta@vyatta:~$ show ip route
Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF, I - ISIS, B - BGP, > - selected route, * - FIB route
S>* 0.0.0.0/0 [1/0] via 10.1.0.1, dp0p0p0
0 10.1.0.0/24 [110/10] is directly connected, dp0p0p0, 05:35:15
0 10.1.0.0/24 [110/10] 13 directly connected, dp0p0p0
0>* 10.192.32.0/24 [110/20] via 10.1.0.45, dp0p0p0, 05:35:15
0>* 10.192.128.0/24 [110/11] via 10.1.0.66, dp0p0p0, 05:35:15
0>* 10.192.128.1/32 [110/11] via 10.1.0.66, dp0p0p0, 05:35:15
O>* 10.192.129.0/24
                              [110/11] via 10.1.0.66, dp0p0p0, 05:35:15
[110/11] via 10.1.0.66, dp0p0p0, 05:35:15
0>* 10.192.130.0/24
0>* 10.192.131.0/24 [110/11] via 10.1.0.66, dp0p0p0, 05:35:15
C>* 127.0.0.0/8 is directly connected, lo
0>* 172.16.0.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.1.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.2.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.3.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.4.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.5.0/24
                           [110/11]
                                        via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.6.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.7.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.8.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
0>* 172.16.9.0/24 [110/11] via 10.1.0.4, dp0p0p0, 05:35:15
C>* 172.16.234.0/25 is directly connected, dp0p0p1
S>* 192.94.202.0/24 [1/0] via 172.16.234.27, dp0p0p1
```

The following example shows how to display information for the route to the 10.192.128.1 IP address.

```
vyatta@vyatta:~$ show ip route 10.192.128.1
Routing entry for 10.192.128.1/32
  Known via "ospf", distance 110, metric 11, best
  Last update 09:47:07 ago
  * 10.1.0.66, via dp0p0p0
vyatta@vyatta:~$
```

# show ip route <ipv4net> longer-prefixes

Displays prefixes in the Routing Information Base (RIB) that are longer than a specific IP address or

prefix.

Syntax show ip route ipv4net longer-prefixes

Parameters ipv4net

Mandatory. An IP address or prefix.

Modes Operational mode

Use this command to display all prefixes in the RIB that are longer than a specific IP address or prefix.

**Examples** The following example shows how to display prefixes that are longer than the 10.192.128.0/24 prefix.

# show ip route connected

Displays directly connected routes.

Syntax show ip route connected

Modes Operational mode

Use this command to display routes that are directly connected to the local system.

**Examples** The following example shows how to display directly connected routes.

## show ip route forward

Displays routes stored in the Forwarding Information Base (FIB).

Syntax show ip route forward [ ipv4net ]

Command Default Displays routes stored in the FIB.

Parameters ipv4net

Optional. A route for which information from the kernel forwarding table is

displayed.

Modes Operational mode

**Usage Guidelines** Use this command to display routes that are stored in the FIB.

The FIB contains multiple equal-cost paths, if they exist. Multiple equal-cost paths are needed before

equal-cost multipath (ECMP) routing or WAN load balancing is performed.

**Examples** The following example shows how to display routes stored in the FIB.

```
vyatta@vyatta:~$ show ip route forward default via 10.1.0.1 dev dp0p0p0 proto zebra
10.1.0.0/24 dev dp0p0p0 proto kernel scope link src 10.1.0.62 10.192.32.0/24 via 10.1.0.45 dev dp0p0p0 proto zebra metric 20 10.192.128.0/24 via 10.1.0.66 dev dp0p0p0 proto zebra metric 11
10.192.128.1 via 10.1.0.66 dev dp0p0p0 proto zebra metric 11 10.192.129.0/24 via 10.1.0.66 dev dp0p0p0 proto zebra metric 11
10.192.130.0/24 via 10.1.0.66 dev dp0p0p0
                                                         proto zebra metric 11
10.192.131.0/24 via 10.1.0.66 dev dp0p0p0 proto zebra metric 11 172.16.0.0/24 via 10.1.0.4 dev dp0p0p0 proto zebra metric 11 172.16.1.0/24 via 10.1.0.4 dev dp0p0p0 proto zebra metric 11
172.16.2.0/24 via 10.1.0.4 dev dp0p0p0
                                                     proto zebra
                                                                      metric 11
172.16.3.0/24 via 10.1.0.4 dev dp0p0p0 proto zebra metric 11
172.16.4.0/24 via 10.1.0.4 dev dp0p0p0
                                                     proto zebra
                                                                       metric 11
172.16.5.0/24 via 10.1.0.4 dev dp0p0p0
                                                     proto zebra metric 11
172.16.6.0/24 via 10.1.0.4 dev dp0p0p0
                                                     proto zebra metric 11
172.16.7.0/24 via 10.1.0.4 dev dp0p0p0 proto zebra metric 11
172.16.8.0/24 via 10.1.0.4 dev dp0p0p0
                                                     proto zebra metric 11
172.16.9.0/24 via 10.1.0.4 dev dp0p0p0 proto zebra metric 11
172.16.234.0/25 dev dp0p0p1 proto kernel scope link src 172.16.234.23
192.94.202.0/24 via 172.16.234.27 dev dp0p0p1 proto zebra
vyatta@vyatta:~$
```

The following example shows how to display information from the FIB about the 10.1.0.0/24 route.

```
vyatta@vyatta:^$ show ip route forward 10.1.0.0/24 10.1.0.0/24 dev dp0p0p0 proto kernel scope link src 10.1.0.62 vyatta@vyatta:^$
```

## show ip route kernel

Displays kernel routes.

Syntax show ip route kernel

Modes Operational mode

**Usage Guidelines** 

Use this command to display kernel routes. Kernel routes are routes that have been added through a means other than by using the Vyatta CLI; for example, by using the operating system **route** command as shown here:

route add -net 10.172.24.0 netmask 255.255.255.0 gw 10.1.0.1

**Examples** 

The following example shows how to display kernel routes.

## show ip route static

Displays static routes in the Routing Information Base (RIB).

Syntax show ip route static

Modes Operational mode

**Examples** The following example shows how to display static routes in the RIB.

## show ip route summary

Displays a summary of routes.

Syntax show ip route summary

Modes Operational mode

**Usage Guidelines** Use this command to display a summary of the various routes by route source.

**Examples** The following example shows how to display a summary of routes.

## show ip route supernets-only

Displays supernet routes.

Syntax show ip route supernets-only

Modes Operational mode

Supernet routes are routes that have a subnet mask that is less specific than the usual classful mask.

**Examples** The following example shows how to display supernet routes.

## show ip route table

Displays routes stored in an alternate routing table.

Syntax show ip route table table-number

Parameters table table-number

An alternate routing table.

Modes Operational mode

Use this command to view routes stored in an alternate routing table. Alternate routing tables are used

with policy-based routing. Refer to Brocade 5600 vRouter Policy-based Routing Reference Guide for

information on policy-based routing.

**Examples** The following example shows how to display routes in the 5 alternate routing table.

vyatta@vyatta:~\$ show ip route table 5
table 5:
Codes: K - kernel route, C - connected, S - static, R - RIP, O - OSPF,
 I - ISIS, B - BGP, > - selected route, \* - FIB route
S>\* 12.34.56.0/24 [1/0] via 192.168.1.254, dp0p0p0
vyatta@vyatta:~\$

## show ipv6 route

Displays IPv6 routes stored in the Routing Information Base (RIB) and Forwarding Information Base

(FIB).

Syntax show ipv6 route [ ipv6 | ipv6net ]

Command Default Displays all IPv6 routes in the RIB and FIB.

Parameters ipv6

Optional. An IPv6 address.

ipv6net

Optional. An IPv6 prefix.

Modes Operational mode

**Use this command to display IPv6 routes stored in the RIB and FIB.** 

You can also see the routes shown in the FIB by using show ip route forward on page 73.

## show ipv6 route <ipv6net> longer-prefixes

Displays IPv6 prefixes in the Routing Information Base (RIB) that are longer than a specific IPv6  $\,$ 

address or prefix.

Syntax show ipv6 route ipv6net longer-prefixes

Parameters ipv6net

Mandatory. An IPv6 address or prefix.

Modes Operational mode

Use this command to display all prefixes in the RIB that are longer than a specific IPv6 address or

prefix.

# show ipv6 route bgp

Displays IPv6 Border Gateway Protocol (BGP) routes.

Syntax show ipv6 route bgp

Modes Operational mode

**Usage Guidelines** Use this command to display IPv6 BGP routes.

# show ipv6 route connected

Displays IPv6 connected routes.

Syntax show ipv6 route connected

Modes Operational mode

## show ipv6 route forward

Displays IPv6 routes stored in the Forwarding Information Base (FIB).

Syntax show ipv6 route forward [ ipv6net ]

Command Default Displays IPv6 routes stored in the FIB.

Parameters ipv6net

Optional. An IPv6 route for which information from the kernel forwarding table is

displayed.

Modes Operational mode

**Usage Guidelines** Use this command to display routes that are stored in the FIB.

The FIB contains multiple equal-cost paths, if they exist. Multiple equal-cost paths are needed before

equal-cost multipath (ECMP) routing or WAN load balancing is performed.

# show ipv6 route kernel

Displays IPv6 kernel routes.

Syntax show ipv6 route kernel

Modes Operational mode

through a means other than by using the Vyatta CLI.

# show ipv6 route ripng

Displays IPv6 Routing Information Protocol next generation (RIPng) routes.

Syntax show ipv6 route ripng

Modes Operational mode

# show ipv6 route static

Displays IPv6 static routes.

Syntax show ipv6 route static

Modes Operational mode

# show monitoring protocols rib

Displays Routing Information Base (RIB) debugging flags.

Syntax show monitoring protocols rib

Modes Operational mode

### traceroute < host > as-path

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host as-path [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

options

The following entries are options. Multiple options can be included on the same command line.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com including AS path information.

```
vyatta@vyatta#traceroute google.com as-path traceroute to google.com (216.58.192.14), 30 hops max, 60 byte packets
    10.18.170.1 (10.18.170.1) [*] 0.681 ms 0.529 ms 0.580 n
10.31.23.6 (10.31.23.6) [*] 0.476 ms 0.433 ms 0.481 ms
    10.31.23.6 (10.31.23.6) [*] 0.476 ms 0.433 ms 0.481 ms 10.254.33.1 (10.254.33.1) [*] 0.864 ms 0.831 ms 0.826 ms
     144.49.130.145 (144.49.130.145) [AS29791/AS21948]
                                                                         8.022 ms
                                                                                       1.183 ms
                                                                                                    1.295 ms
     ae6-395.edge8.sanjose1.level3.net (209.244.104.65) [AS3356]
                                                                                      2.106 ms
2.006 ms
 6 ae-1-60.edge1.sanjose3.level3.net (4.69.152.16) [AS3356]
                                                                                  2.887 ms * *
     72.14.223.91 (72.14.223.91) [AS15169] 2.878 ms
                                                                       2.972 ms
                                                                                    2.938 ms
     209.85.249.3 (209.85.249.3) [AS15169] 3.430 ms 4.754 ms
9 74.125.37.41 (74.125.37.41) [AS15169] 4.568 ms 4.516 ms 4.455 ms
10 nuq04s29-in-f14.1e100.net (216.58.192.14) [AS15169] 3.159 ms 3.134 ms 3.097 ms
```

## traceroute <host> bypass-routing

Displays the route that packets take to a network host.

Syntax traceroute [ipv4 | ipv6 ] host bypass-routing [options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com bypassing the normal routing tables. Note that an error message appears because google.com is not on a directly attached network.

vyatta@vyatta#traceroute google.com bypass-routing
traceroute to google.com (216.58.192.14), 30 hops max, 60 byte packets
connect:network is unreachable

### traceroute <host> debug-socket

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host debug-socket [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

debug-socket

Enables socket level debugging.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with socket level debugging enabled.

```
vyatta@vyatta#traceroute google.com debug-socket traceroute to google.com (216.58.216.14), 30 hops max, 60 byte packets 1 gateway.attlocal.net (10.0.6.1) 0.422 ms 0.399 ms 0.498 ms
    75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214) 16.520 ms 6.484 ms 6.460
   76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2) 33.529 ms 36.814 ms
   71.145.0.192 (71.145.0.192)
                                     26.546 ms
                                                  39.056 ms
   12.83.39.189 (12.83.39.189) 39.763 ms
                                                  30.819 ms
   12.122.136.181 (12.122.136.181) 44.407 ms 43.366 ms
   216.239.49.170 (216.239.49.170) 28.635 ms 216.239.49.168 (216.239.49.168) 28.293
                                                                      216.239.49.170
(216.239.49.170) 25.805 ms
   209.85.246.253 (209.85.246.253) 32.914 ms 34.112 ms 209.85.246.20
(209.85.246.20) 30.330 ms
10 64.233.174.204 (64.233.174.204)
11 64.233.175.151 (64.233.175.151)
                                           36.979 ms
                                                        36.492 ms 38.584 ms
                                                        37.496 ms 64.233.174.189
                                           37.497 ms
(64.233.174.189) 37.503 ms
12 209.85.142.91 (209.85.142.91) 36.126 ms 36.735 ms 36.686 ms
13 lax02s21-in-f14.1e100.net (216.58.216.14) 34.280 ms 32.453 ms 31.764 ms
```

### traceroute <host> first-ttl <value>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host first-ttl value [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with the first time-to-live set to 3.

### traceroute <host> gateway <address>

Displays the route that packets take to a network host.

Syntax traceroute [ipv4 | ipv6 ] host gateway address [options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

gateway address

Routes the request through a specified gateway.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default

is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with the gateway set.

vyatta@vyatta#traceroute google.com gateway

### traceroute <host> icmp-echo

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host icmp-echo [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

icmp-echo

Uses ICMP echo for the traceroute probe.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com using ICMP echo for the traceroute probe.

```
vyatta@vyatta#traceroute google.com icmp-echo
traceroute to google.com (74.125.224.9), 30 hops max, 60 byte packets
1    gateway.attlocal.net (10.0.6.1)    0.512 ms    0.510 ms    0.507 ms
2    75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)    3.175 ms    3.194 ms    3.194
ms
3    76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)    24.351 ms    25.192
ms    25.201 ms
4    71.145.0.192 (71.145.0.192)    26.644 ms    27.905 ms    27.910 ms
5    12.83.39.185 (12.83.39.185)    28.728 ms    32.328 ms    32.335 ms
6    12.122.136.181 (12.122.136.181)    68.186 ms    67.898 ms    67.853 ms
7    * * *
8    216.239.49.168 (216.239.49.168)    25.336 ms    26.631 ms    27.460 ms
9    72.14.232.33 (72.14.232.33)    26.151 ms    26.620 ms    27.186 ms
10    nuq04s18-in-f9.1e100.net (74.125.224.9)    27.531 ms    24.783 ms    24.752 ms
```

### traceroute <host> icmp-extensions

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host icmp-extensions [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com showing ICMP extensions.

```
vyatta@vyatta#traceroute google.com icmp-extensions
traceroute to google.com (74.125.224.1), 30 hops max, 60 byte packets
1 gateway.attlocal.net (10.0.6.1) 0.482 ms 0.458 ms 0.452 ms
2 75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214) 13.714 ms 13.703 ms
13.673 ms
3 76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2) 35.518 ms 34.284 ms
35.492 ms
4 71.145.0.192 (71.145.0.192) 34.201 ms 35.828 ms 35.385 ms
5 12.83.39.189 (12.83.39.189) 39.513 ms 12.83.39.185 (12.83.39.185) 39.510 ms
12.83.39.189 (12.83.39.189) 44.236 ms
6 12.122.136.181 (12.122.136.181) 47.009 ms 46.105 ms 46.052 ms
7 * * *
8 216.239.49.168 (216.239.49.168) 31.725 ms 28.023 ms 28.467 ms
9 72.14.232.33 (72.14.232.33) 32.480 ms 31.081 ms 31.791 ms
10 nuq04s18-in-f1.1e100.net (74.125.224.1) 32.791 ms 26.412 ms 25.713 ms
```

### traceroute <host> interface <value>

Displays the route that packets take to a network host.

**Syntax** traceroute [ ipv4 | ipv6 ] host interface value [ options ]

**Parameters** ipv4

> Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, traceroute will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, traceroute will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h).

interface value

Specifies the interface that the device must use for traceroute requests.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default

is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com through interface dp0p1s2.

vyatta@vyatta#traceroute google.com interface dp0p1s2

### traceroute <host> max-ttl <value>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host max-ttl value [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

max-ttl value

Specifies the maximum number of hops for the probe.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with a maximum of 4 hops.

```
vyatta@vyatta#traceroute google.com max-ttl 4
traceroute to google.com (74.125.224.8), 4 hops max, 60 byte packets
1  gateway.attlocal.net (10.0.6.1)  0.362 ms  0.333 ms  0.340 ms
2  75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)  9.559 ms  9.553 ms  9.529 ms
3  76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)  30.061 ms  31.737 ms
4  71.145.0.192 (71.145.0.192)  31.776 ms  31.763 ms  31.758 ms
```

### traceroute <host> interval <value>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host interval value [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

interval value

Specifies the time in seconds between traceroute requests from the device.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

num-queries number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default

is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with 3 seconds between traceroute requests.

vyatta@vyatta#traceroute google.com interval 3

### traceroute <host> max-ttl <value>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host max-ttl value [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

max-ttl value

Specifies the maximum number of hops for the probe.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

no-fragment

Does not fragment the probe packets.

num-queries number

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with a maximum of 4 hops.

```
vyatta@vyatta#traceroute google.com max-ttl 4
traceroute to google.com (74.125.224.8), 4 hops max, 60 byte packets
1  gateway.attlocal.net (10.0.6.1)  0.362 ms  0.333 ms  0.340 ms
2  75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)  9.559 ms  9.553 ms  9.529 ms
3  76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)  30.061 ms  31.737 ms
4  71.145.0.192 (71.145.0.192)  31.776 ms  31.763 ms  31.758 ms
```

## traceroute < host > no-fragment

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host no-fragment [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

no-fragment

Does not fragment the probe packets.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

num-queries number

Specifies the number of probe packets per hop. The default is 3.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with no fragmented probe packets.

```
vyatta@vyatta#traceroute google.com no-fragment
traceroute to google.com (74.125.224.0), 30 hops max, 60 byte packets
1 pipsqueak.attlocal.net (10.0.6.1)  0.394 ms  0.564 ms  0.356 ms
2  75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)  9.799 ms  9.771 ms  9.748
ms
3  76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)  31.504 ms  30.107 ms
36.088 ms
4  71.145.0.192 (71.145.0.192)  36.139 ms  31.473 ms  31.441 ms
5  12.83.39.189 (12.83.39.189)  38.391 ms  37.441 ms  12.83.39.185 (12.83.39.185)
36.589 ms
6  12.122.136.181 (12.122.136.181)  83.786 ms  82.908 ms  82.880 ms
7  * * *
8  216.239.49.168 (216.239.49.168)  27.049 ms  36.183 ms  33.859 ms
9  72.14.232.33 (72.14.232.33)  33.652 ms  33.064 ms  33.645 ms
10  nuq04s18-in-f0.1e100.net (74.125.224.0)  36.182 ms  36.165 ms  36.142 ms
```

## traceroute <host> num-queries <num>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host num-queries number [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

num-queries number

Specifies the number of probe packets per hop. The default is 3.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

#### tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with 4 probes per hop.

```
vyatta@vyatta#traceroute google.com num-queries 2
traceroute to google.com (74.125.224.9), 30 hops max, 60 byte packets
1 gateway.attlocal.net (10.0.6.1) 0.411 ms 0.387 ms
2 75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214) 14.167 ms 14.145 ms
3 76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2) 36.338 ms 35.080 ms
4 71.145.0.192 (71.145.0.192) 36.862 ms 36.338 ms
5 12.83.39.189 (12.83.39.189) 49.387 ms 12.83.39.185 (12.83.39.185) 49.374 ms
6 12.122.136.181 (12.122.136.181) 41.428 ms 41.419 ms
7  **
8 216.239.49.168 (216.239.49.168) 41.356 ms 49.198 ms
9 72.14.232.33 (72.14.232.33) 39.738 ms 39.720 ms
10 nuq04s18-in-f9.le100.net (74.125.224.9) 34.504 ms 34.474 ms
```

## traceroute <host> port <number>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host port number [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*: followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

#### no-fragment

Does not fragment the probe packets.

num-queries number

Specifies the number of probe packets per hop. The default is 3.

seq-queries number

Specifies the number of sequential probe packets.

source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC

address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default

is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com through port 80.

```
vyatta@vyatta#traceroute google.com port 80
traceroute to google.com (74.125.224.1), 30 hops max, 60 byte packets
1 gateway.attlocal.net (10.0.6.1) 0.383 ms 0.327 ms 0.327 ms
2 75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214) 1.689 ms 1.582 ms 1.461 ms
3 76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2) 22.674 ms 21.656 ms 21.901 ms
4 71.145.0.192 (71.145.0.192) 26.552 ms 21.609 ms 21.732 ms
5 12.83.39.185 (12.83.39.185) 23.492 ms 12.83.39.189 (12.83.39.189) 24.755 ms 12.83.39.185 (12.83.39.185) 23.333 ms
6 12.122.136.181 (12.122.136.181) 23.033 ms 22.736 ms 23.119 ms
7 * * *
8 216.239.49.168 (216.239.49.168) 25.157 ms 24.775 ms 24.790 ms
9 72.14.232.33 (72.14.232.33) 25.859 ms 25.051 ms 25.207 ms
10 nuq04s18-in-f1.1e100.net (74.125.224.1) 25.102 ms 24.958 ms 25.077 ms
```

## traceroute <host> seq-queries <number>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host seq-queries number [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

seq-queries number

Specifies the number of sequential probe packets.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### num-queries number

Specifies the number of probe packets per hop. The default is 3.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with 2 sequential probe packets.

```
vyatta@vyatta#traceroute google.com seq-queries 2
traceroute to google.com (74.125.224.0), 30 hops max, 60 byte packets
1 pipsqueak.attlocal.net (10.0.6.1)  0.441 ms  0.416 ms  0.357 ms
2  75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)  1.762 ms  2.295 ms  1.497
ms
3  76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)  23.357 ms  22.565 ms
22.219 ms
4  71.145.0.192 (71.145.0.192)  23.964 ms  22.780 ms  21.566 ms
5  12.83.39.185 (12.83.39.185)  27.362 ms 12.83.39.189 (12.83.39.189)  26.326 ms
12.83.39.185 (12.83.39.185)  25.436 ms
6  12.122.136.181 (12.122.136.181)  113.918 ms  88.183 ms  49.824 ms
7  * * *
8  216.239.49.168 (216.239.49.168)  26.184 ms  24.964 ms  24.673 ms
9  72.14.232.33 (72.14.232.33)  25.629 ms  25.079 ms  25.069 ms
10  nuq04s18-in-f0.1e100.net (74.125.224.0)  25.164 ms  25.286 ms  24.878 ms
```

### traceroute <host> source-addr <host>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host source-addr host [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### num-queries number

Specifies the number of probe packets per hop. The default is 3.

port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

seq-queries number

Specifies the number of sequential probe packets.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default

is 5 seconds.

Modes Operational mode

**Usage Guidelines** 

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

**Examples** 

The following example illustrates a traceroute to google.com with source address client1.attlocal.net.

vyatta@vyatta#traceroute google.com source-addr client.attlocal.net

## traceroute <host> tcp-syn

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host tcp-syn [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

tcp-syn

Uses TCP SYN for the probes.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### num-queries number

Specifies the number of probe packets per hop. The default is 3.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com using tcp-syn for probes.

```
vyatta@vyatta#traceroute google.com tcp-syn
traceroute to google.com (74.125.224.6), 30 hops max, 60 byte packets
1 gateway.attlocal.net (10.0.6.1)  0.389 ms  0.341 ms  0.316 ms
2  75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)  12.784 ms  12.767 ms
12.771 ms
3  76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)  35.539 ms  35.529 ms
35.517 ms
4  71.145.0.192 (71.145.0.192)  35.512 ms  35.503 ms  33.653 ms
5  12.83.39.189 (12.83.39.189)  38.888 ms  36.371 ms  37.952 ms
6  12.122.136.181 (12.122.136.181)  63.947 ms  63.087 ms  63.045 ms
7  * * *
8  216.239.49.168 (216.239.49.168)  28.752 ms  29.378 ms  29.368 ms
9  * * *
10  nug04s18-in-f6.1e100.net (74.125.224.6)  29.669 ms  27.836 ms  29.669 ms
```

### traceroute <host> tos <value>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host tos value [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

tos value

Marks the packets with the specified Type of Service (TOS) value.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### num-queries number

Specifies the number of probe packets per hop. The default is 3.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

version

Displays the timestamp during ping output.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com with packets marked with tos equal to 3.

```
vyatta@vyatta#traceroute google.com tos 3
traceroute to google.com (74.125.224.2), 30 hops max, 60 byte packets
1 gateway.attlocal.net (10.0.6.1) 0.374 ms 0.550 ms 0.353 ms
2 75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214) 7.270 ms 15.975 ms 7.238
ms
3 76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2) 29.199 ms 38.969 ms
28.635 ms
4 71.145.0.192 (71.145.0.192) 35.803 ms 36.212 ms 28.590 ms
5 12.83.39.189 (12.83.39.189) 34.061 ms 32.033 ms 42.496 ms
6 12.122.136.181 (12.122.136.181) 39.973 ms 41.665 ms 41.608 ms
7 * * *
8 216.239.49.168 (216.239.49.168) 29.549 ms 26.607 ms 26.583 ms
9 72.14.232.33 (72.14.232.33) 28.133 ms 27.602 ms 29.294 ms
10 nuq04s18-in-f2.1e100.net (74.125.224.2) 28.553 ms 30.071 ms 28.028 ms
```

### traceroute < host > version

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host version [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

version

Displays the timestamp during ping output.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is CLASS/TYPE:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### num-queries number

Specifies the number of probe packets per hop. The default is 3.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com showing timestamp during ping output.

vyatta@vyatta#traceroute google.com version

### traceroute <host> wait-time <value>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host wait-time value [ options ]

Parameters ipv4

Explicitly force IPv4 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv4.

ipv6

Explicitly force IPv6 traceouting. By default, the program will try to resolve the name given, and choose the appropriate protocol automatically. If resolving a host name returns both IPv4 and IPv6 addresses, **traceroute** will use IPv6.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC address (format h:h:h:h:h:h:h:h:h).

wait-time value

Specifies the time (seconds) to wait for a response from the probe. Default is 5 seconds.

options

The following entries are options. Multiple options can be included on the same command line.

as-path

Performs AS path lookups in routing registries and print results directly after the corresponding addresses.

bypass-routing

Bypasses the normal routing tables and send directly to a host on an attached network. If the host is not on a directly-attached network, an error is returned. This option can be used to ping a local host through an interface that has no route through it.

debug-socket

Enables socket level debugging.

first-ttl value

Specifies the first time-to-live value. Defaults to 1.

gateway address

Routes the request through a specified gateway.

icmp-echo

Uses ICMP echo for the traceroute probe.

icmp-extensions

Shows ICMP extensions (rfc4884). The general form is *CLASS/TYPE*:

followed by a hexadecimal dump.

interface value

Specifies the interface that the device must use for traceroute requests.

interval value

Specifies the time in seconds between traceroute requests from the device.

max-ttl value

Specifies the maximum number of hops for the probe.

no-fragment

Does not fragment the probe packets.

#### num-queries number

Specifies the number of probe packets per hop. The default is 3.

#### port number

For UDP tracing, specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). For ICMP tracing, specifies the initial icmp sequence value (incremented by each probe too). For TCP specifies just the (constant) destination port to connect.

#### seq-queries number

Specifies the number of sequential probe packets.

#### source-addr host

Specifies an alternative source host by hostname, IPv4 address, or MAC address.

tcp-syn

Uses TCP SYN for the probes.

tos value

Marks the packets with the specified Type of Service (TOS) value.

version

Displays the timestamp during ping output.

#### Modes Operational mode

#### **Usage Guidelines**

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

#### **Examples**

The following example illustrates a traceroute to google.com waiting 2 seconds between probes.

```
vyatta@vyatta#traceroute google.com wait-time 2
traceroute to google.com (74.125.224.2), 30 hops max, 60 byte packets
1 pipsqueak.attlocal.net (10.0.6.1)  0.409 ms  0.452 ms  0.346 ms
2  75-25-153-214.uvs.sntcca.sbcglobal.net (75.25.153.214)  13.497 ms  13.517 ms
13.509 ms
3  76-198-128-2.lightspeed.mtvwca.sbcglobal.net (76.198.128.2)  35.910 ms  34.763 ms
35.876 ms
4  71.145.0.192 (71.145.0.192)  35.981 ms  35.979 ms  34.775 ms
5  12.83.39.189 (12.83.39.189)  39.654 ms  39.662 ms  44.599 ms
6  12.122.136.181 (12.122.136.181)  85.423 ms  84.396 ms  84.358 ms
7  * * *
8  216.239.49.168 (216.239.49.168)  33.291 ms  27.613 ms  28.017 ms
9  72.14.232.33 (72.14.232.33)  45.214 ms  45.849 ms  44.999 ms
10 nuq04s18-in-f2.1e100.net (74.125.224.2)  30.505 ms  29.739 ms  30.298 ms
```

# traceroute <protocol> <host>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host [ option ]

Parameters ipv4

Displays the route that packets take to the IPv4 address of the host. This keyword is used when the host is specified as a host name rather than as an IP

address.

ipv6

Displays the route that packets take to the IPv6 address of the host. This keyword is used when the host is specified as a host name rather than as an IP

address.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), as an IPv4 or IPv6 address, or as a MAC

address (format <h:h:h:h:h:h:h:h).

option

Displays the route that packets take to the host. This keyword is used when the

host is specified as a host name rather than as an IP address.

Modes Operational mode

**Usage Guidelines** 

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

### traceroute < host>

Displays the route that packets take to a network host.

Syntax traceroute [ ipv4 | ipv6 ] host

Parameters ipv4

Displays the route that packets take to the IPv4 address of the host. This keyword is used when the host is specified as a host name rather than as an IP

address.

ipv6

Displays the route that packets take to the IPv6 address of the host. This keyword is used when the host is specified as a host name rather than as an IP

address.

host

A host that is the destination for the trace. The host is specified as a name (if DNS is being used on the network), an IPv4 or IPv6 address, or MAC address.

Modes Operational mode

**Usage Guidelines** 

Use this command to perform a "traceroute" operation for a network host. This operation uses the IP protocol time-to-live (TTL) field and attempts to elicit an Internet Control Message Protocol (ICMP) TIME\_EXCEEDED response from each gateway along the path to a host to track the route that a set of packets follows. It attempts to trace the route an IP packet follows to an Internet host by launching User Datagram Protocol (UDP) probe packets with a small time to live, then listening for an ICMP "Time exceeded" reply from a gateway.

traceroute <host>

# **ECMP**

<ul> <li>FCMP overview</li> </ul>	40	٠,
• FUVIP OVELVIEW	11.7	١.

# **ECMP** overview

ECMP is a technique that routes packets along multiple paths of equal cost. ECMP provides a load-balancing mechanism to ensure optimum usage of a routing path.

The Brocade vRouter supports the following load-balancing mechanisms:

- · Modulo-n-hash
- · Hash-threshold
- · Highest Random Weight (HRW)

The Brocade vRouter calculates the key of the packet flow for every ECMP selection algorithm. The next-hop selection algorithm calculates the key of the flow and chooses the next hop.

The Brocade vRouter supports the HRW load-balancing mechanism by default. You can change the ECMP mode, if required.

ECMP is enabled on Border Gateway Protocol (BGP) by configuring the maximum number of ECMP routes for External BGP (eBGP) or Internal BGP (iBGP).

ECMP overview

# **ECMP Commands**

protocols ecmp disable	134
protocols ecmp maximum-paths	135
• protocols ecmp mode <mode></mode>	136
show dataplane route	137
show dataplane route6	138

# protocols ecmp disable

Disables ECMP routing.

Syntax set protocols ecmp disable

Command Default None.

Modes Configuration mode.

Configuration Statement

protocols {
 ecmp {
 disable {}
}

# protocols ecmp maximum-paths

Sets the maximum number of next hops for ECMP routing.

Syntax set protocols ecmp maximum-paths number

delete protocols ecmp maximum-paths

Command Default None

Parameters maximum-paths number

Sets the maximum number of next hops for ECMP routing.

Modes Configuration mode.

Configuration Statement

```
protocols {
   ecmp {
      maximum-paths number{}
}
```

**Usage Guidelines** 

Use the **set** form of this command to set the maximum number of next hops for ECMP routing.

Use the **delete** form of this command to remove the maximum number of next hops for ECMP routing.

# protocols ecmp mode <mode>

Sets the load-balancing mechanism for ECMP.

Syntax set protocols ecmp mode hash-threshold | hrw | modulo-n

delete protocols ecmp mode hash-threshold | hrw | modulo-n

show protocols ecmp mode hash-threshold | hrw | modulo-n

#### **Command Default**

None

#### **Parameters**

hash-threshold

Sets the hash-threshold ECMP routing mode.

hrw

Sets the highest random weight ECMP routing mode. This mode is the default.

modulo-n

Sets the modulo-n-hash ECMP routing mode.

#### Modes

Configuration mode.

# Configuration Statement

```
protocols {
    ecmp {
        mode {
            hash-threshold
            hrw
            modulo-n
        }
}
```

#### **Usage Guidelines**

Use the set form of this command to set the load-balancing mechanism for ECMP.

Use the **delete** form of this command to remove the load-balancing mechanism. The ECMP load-balancing mechanism returns to its default setting, which is HRW.

Use the **show** form of this command to display the current load-balancing mechanism for ECMP.

#### **Examples**

The following example shows how to set the hash-threshold mode with maximum number of next hops as 34 for ECMP routing.

```
vyatta@vyatta# set protocols ecmp maximum-paths 34
[edit]
vyatta@vyatta# set protocols ecmp mode hash-threshold
[edit]
vyatta@vyatta# commit
```

The output for the ECMP configuration is as follows.

# show dataplane route

Displays forward information base (FIB) table that contain all routes including ECMP routes.

Syntax show dataplane route

Parameters None.

Modes Operational mode.

**Usage Guidelines** Use this command to display the FIB table.

**NOTE** 

FIB table is stored in the data plane.

# show dataplane route6

Displays FIB table that contain all IPv6 routes including ECMP routes.

Syntax show dataplane route6

Parameters None

Modes Operational mode.

### **Static Routes**

•	Static route configuration	13	39
•	Static IPv6 route configuration.	14	41

# **Static route configuration**

This section presents the following topics:

- Static routes overview on page 139
- · Configuring static routes on page 139
- · Creating floating static routes on page 140
- · Showing static routes in the routing table on page 141

#### Static routes overview

A static route is a manually configured route, which, in general, cannot be updated dynamically from information about the network topology learned by the Brocade vRouter. However, if a link fails, the router removes the routes, including static routes, from the Routing Information Base (RIB) that use this interface to reach the next hop.

Usually, static routes should be used only for very simple network topologies, or to override the behavior of a dynamic routing protocol for a small number of routes.

The collection of all routes the router learns from its configuration, or from its dynamic routing protocols, is stored in its RIB.


Unicast routes are directly used to determine the forwarding table for unicast packet forwarding.

Blackhole routes are static unreachable routes that can be configured to send ICMP unreachable responses on packets.

### **Configuring static routes**

Figure 1 presents sample configurations of basic static routes. When you are finished with Configuring static routes, the system is configured as shown in the figure. In the example, a static route is created that says, in effect, "any packets destined for the 11.0.0.0/8 network should be forwarded to 172.16.0.26."

FIGURE 1 Static routes



This section includes the following example:

· Configuring static routes

Table 1 shows how to create a static route to the 11.0.0.0/8 network that is directed toward 172.16.0.26.

To create a static route, perform the following steps in configuration mode.

TABLE 1 Creating a static route

Step	Command
Create a static route to R2.	vyatta@Rl# set protocols static route 11.0.0.0/8 next-hop 172.16.0.26
Commit the configuration.	vyatta@R1# commit
View the configuration.	<pre>vyatta@R1# show protocols static route route 11.0.0.0/8 {   next-hop 172.16.0.26 {   } }</pre>

### **Creating floating static routes**

Usually, static routes have a relatively short administrative distance—typically 1, and normally shorter than the administrative distances for dynamic (learned) routes. A "floating" static route is a static route with an administrative distance greater than the administrative distance for dynamic routes.

You can configure a static route to be a floating route by setting the administrative distance higher than the distance applied to the routes in your dynamic routing protocol. This higher distance renders

the static route less desirable than a dynamic route. At the same time, if the dynamic route is lost, the static route is available to take over traffic, which can be forwarded through the static route as an alternate path.

#### **NOTE**

When configuring the administrative distance (AD) of a protocol, keep in mind when you specify the distance value of 255, the router will disbelieve the source and will not add the route to the routing table.

### Showing static routes in the routing table


To display route information, use the **show ip route** command. To show just static routes, use the **show ip route static** command, as shown in the following example.

#### Showing static routes in the routing table

# Static IPv6 route configuration

Figure 2 shows an IPv6 network with three nodes. Verify that IPv6 forwarding is enabled on page 142 shows how to configure nodes that use static routes to enable R2 and R4 to communicate through R1.

FIGURE 2 Static IPv6 routing example



### Verify that IPv6 forwarding is enabled

For R1 to be able to pass data between the dp0p0p0 and dp0p0p2 interfaces (that is, between R4 and R2), R1 must be configured to enable forwarding. To determine if forwarding is enabled, perform the following step in operational mode.

TABLE 2 Determining if forwarding is enabled on R1

Step	Command
Display the state of IPv6 forwarding on R1.	vyatta@R1:~\$ show ipv6 forwarding ipv6 forwarding is off

If forwarding is not enabled, as in the example below, the system must be configured to enable forwarding. To enable forwarding, perform the following steps in configuration mode.

TABLE 3 Enabling forwarding on R1

Step	Command
Enable forwarding on R1.	vyatta@R1# delete system ipv6 disable-forwarding
Commit the change.	vyatta@R1# commit
Change to operational mode.	vyatta@R1# exit exit vyatta@R1:~\$
Display the state of IPv6 forwarding on R1.	vyatta@R1:~\$ show ipv6 forwarding ipv6 forwarding is on

### Add the default IPv6 route

On R4, all traffic that is not routed elsewhere is sent to R1. To configure the default route, perform the following steps in configuration mode.

TABLE 4 Adding the default route on R4

Step	Command
Add the default route on R4.	<pre>vyatta@R4# set protocols static route6 ::/0 next-hop 2001:db8:1::1</pre>
Commit the change.	vyatta@R4# commit
Change to operational mode.	vyatta@R4# exit exit vyatta@R4:~\$

**TABLE 4** Adding the default route on R4 (Continued)

### Add a static IPv6 route

As an alternative to the default route created on R4, create a static route on R2. To configure a static route to the 2001:db8:1::/64 network, perform the following steps in configuration mode.

**TABLE 5** Adding a static route on R2

•	
Step	Command
Add a static route on R2.	<pre>vyatta@R1# set protocols static route6 2001:db8:1::/64 next-hop 2001:db8:2::1</pre>
Commit the change.	vyatta@R1# commit
Change to operational mode.	vyatta@R1# exit exit vyatta@R2:~\$
Verify the static route in the routing table.	<pre>vyatta@R2:~\$ show ipv6 route Codes: K - kernel route, C - connected, S - static, R - RIPng, O - OSPFv3,</pre>

# **Confirm connectivity**

To confirm that R2 and R4 can communicate, use the **ping** command. To confirm connectivity between R2 and R4, perform the following step in operational mode.

TABLE 6 Confirming connectivity between R2 and R4

Step	Command	
Ping R4 from R2.	<pre>vyatta@R2:~\$ ping 2001:db8:1::4 PING 2001:db8:1::4(2001:db8:1::4) 56 data bytes 64 bytes from 2001:db8:1::4: icmp_seq=1 ttl=63 time=5.65 ms 64 bytes from 2001:db8:1::4: icmp_seq=2 ttl=63 time=0.382 ms ^C 2001:db8:1::4 ping statistics 2 packets transmitted, 2 received, 0% packet loss, time 1011ms rtt min/avg/max/mdev = 0.382/3.016/5.650/2.634 ms</pre>	

As an alternative, use the **traceroute** command to verify that the route goes from R2 to R1 to R4. To confirm connectivity between R2 and R4 through R1 by using the **traceroute** command, perform the following step in operational mode.

TABLE 7 Confirming connectivity between R2 and R4 through R1

Step	Command
Trace the route from R2 to R4.	<pre>vyatta@R2:~\$ traceroute 2001:db8:1::4 traceroute to 2001:db8:1::4 (2001:db8:1::4), 30 hops max, 40 byte packets 1 (2001:db8:2::1) 4.448 ms 4.148 ms 4.092 ms 2 (2001:db8:1::4) 4.297 ms 4.306 ms 4.308 ms</pre>

### **Static Route Commands**

• protocols static interface-route <subnet> next-hop-interface <interface></interface></subnet>	146
• protocols static interface-route6 <subnet> next-hop-interface <interface></interface></subnet>	147
protocols static route <subnet> blackhole <distance></distance></subnet>	148
• protocols static route <subnet> next-hop <address></address></subnet>	149
protocols static route6 <subnet> blackhole</subnet>	150
• protocols static route6 <subnet> next-hop <address></address></subnet>	15 <sup>2</sup>
• protocols static table  interface-route <subnet> next-hop-interface</subnet>	
<interface></interface>	152
• protocols static table  route <subnet> blackhole <distance></distance></subnet>	153
• protocols static table  route <subnet> next-hop <address></address></subnet>	154
• protocols static table  route6 <subnet> next-hop <address></address></subnet>	158
protocols static table  route6 <subnet> blackhole [distance]</subnet>	156

## protocols static interface-route <subnet> next-hop-interface <interface>

Configures the next-hop interface for an interface-based static route.

#### **Syntax**

set protocols static interface-route subnet next-hop-interface interface [ disable | distance distance ]

delete protocols static interface-route subnet next-hop-interface interface [ disable | distance ]

show protocols static interface-route subnet next-hop-interface interface [ disable | distance ]

#### **Parameters**

#### interface-route subnet

Multi-node. An interface-based static route. The format is a destination subnet of the form *address/prefix* (*h:h:h:h:h:h:h:h:x*).

You can define multiple interface-based routes by creating multiple **interface-route** configuration nodes.

#### next-hop-interface interface

The next-hop interface.

#### disable

Disables the interface-based static route.

#### distance distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance. The distance ranges from 1 through 255. The default distance is 1.

#### Modes

Configuration mode

### Configuration Statement

#### **Usage Guidelines**

Use the **set** form of this command to configure the next-hop interface for a static route.

Use the **delete** form of this command to remove the next-hop interface from a static route.

Use the **show** form of this command to view the next-hop interface for a static route.

## protocols static interface-route6 <subnet> next-hop-interface <interface>

Configures the next-hop interface for an interface-based IPv6 static route.

**Syntax** 

set protocols static interface-route6 subnet next-hop-interface interface [ disable | distance distance ]

delete protocols static interface-route6 subnet next-hop-interface interface [ disable | distance ]

show protocols static interface-route6 subnet next-hop-interface interface [ disable | distance ]

**Parameters** 

interface-route6 subnet

Multi-node. An interface-based static route. The format is a destination subnet of the form *address/prefix* (*h:h:h:h:h:h:h:h:h*).

You can define multiple interface-based routes by creating multiple **interface-route** configuration nodes.

next-hop-interface interface

The next-hop interface.

disable

Disables the interface-based IPv6 static route.

distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance.

Modes

Configuration mode

### Configuration Statement

**Usage Guidelines** 

Use the **set** form of this command to configure the next-hop interface for an IPv6 static route.

Use the **delete** form of this command to remove the next-hop interface from an IPv6 static route.

Use the **show** form of this command to view the next-hop interface for an IPv6 static route.

### protocols static route <subnet> blackhole <distance>

Configures a black hole static route.

Syntax set protocols static route subnet blackhole [ distance distance ]

delete protocols static route subnet blackhole [ distance ]

show protocols static route subnet blackhole [ distance ]

#### Parameters route subnet

Multi-node. A static route. The format is a destination subnet of the form address/prefix (x.x.x.xlx).

You can define multiple static routes by creating multiple **route** configuration nodes.

#### blackhole

A destination router that is offline and cannot receive traffic or provide messages to the source of the traffic.

#### distance distance

The black hole distance for this route. Routes with a smaller distance are selected before those with a larger distance. The distance ranges from 1 through 255. The default distance is 1.

#### Modes

Configuration mode

### Configuration Statement

#### **Usage Guidelines**

A black hole static route is a route for which the system silently discards packets that are matched.

Use the **set** form of this command to configure a black hole static route.

Use the delete form of this command to remove a black hole static route.

Use the **show** form of this command to view a black hole static route.

### protocols static route <subnet> next-hop <address>

Configures the next hop for a static route.

Syntax set protocols static route subnet next-hop address [ disable | distance distance ]

delete protocols static route subnet next-hop address [ disable | distance ]

show protocols static route subnet next-hop address [ disable | distance ]

Parameters route subnet

Multi-node. A static route. The format is a destination subnet of the form

address/prefix (x.x.x.xlx).

You can define multiple static routes by creating multiple route configuration

nodes.

address

The address of the next-hop router.

disable

Disables the static route.

distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance. The distance ranges from 1

through 255. The default distance is 1.

Modes Configuration mode

#### Configuration Statement

#### **Usage Guidelines**

Use the **set** form of this command to configure the next hop for a static route.

Use the **delete** form of this command to remove the next hop from a static route.

Use the **show** form of this command to view the next hop for a static route.

### protocols static route6 < subnet > blackhole

Configures a black hole IPv6 static route.

Syntax set protocols static route6 subnet blackhole [distance number]

delete protocols static route6 subnet blackhole [ distance number ]

show protocols static route6 subnet blackhole [ distance number ]

Parameters route6 subnet

Multi-node. An IPv6 static route. The format is a destination subnet of the form IPv6- address/prefix (h:h:h:h:h:h:h:h)x).

You can define multiple static routes by creating multiple **route** configuration nodes.

blackhole distance

The black hole distance for this route. Routes with a smaller distance are selected before those with a larger distance.

Modes Configuration mode

Configuration Statement

```
protocols {
    static {
        route6 subnet {
            blackhole {
                  distance distance
            }
        }
}
```

**Usage Guidelines** 

A black hole static route silently discards packets that are matched.

Use the **set** form of this command to configure a black hole IPv6 static route.

Use the delete form of this command to remove a black hole IPv6 static route.

Use the **show** form of this command to view a black hole IPv6 static route.

### protocols static route6 <subnet> next-hop <address>

Configures the next hop for an IPv6 static route.

#### **Syntax**

set protocols static route6 subnet next-hop address [ disable | distance distance | interface interface ]

delete protocols static route6 subnet next-hop address [ disable | distance | interface ]

show protocols static route6 subnet next-hop address [ disable | distance | interface ]

#### **Parameters**

#### route6 subnet

Multi-node. An IPv6 static route. The format is a destination subnet of the form IPv6- address/prefix (h:h:h:h:h:h:h:h:h).

You can define multiple static routes by creating multiple **route6** configuration nodes.

#### next-hop address

The IPv6 address of the next hop router.

#### disable

Disables the IPv6 static route.

#### distance distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance.

#### interface

The outgoing interface used to reach the next-hop address. This interface is needed when the next-hop address is a link-local address (that is, it has a fe80::/64 prefix).

#### Modes

#### Configuration mode

### Configuration Statement

#### **Usage Guidelines**

Use this command to configure IPv6 static routes on the router.

Use the **set** form of this command to configure the next hop for an IPv6 static route.

Use the **delete** form of this command to remove the next hop from an IPv6 static route.

Use the **show** form of this command to view the next hop for an IPv6 static route.

# protocols static table interface-route <subnet> next-hop-interface <interface>

Configures the next-hop interface for an interface-based static route in an alternate routing table.

#### **Syntax**

set protocols static table table interface-route subnet next-hop-interface interface [ disable | distance distance ]

delete protocols static table table interface-route subnet next-hop-interface interface [ disable | distance ]

show protocols static table *table* interface-route *subnet* next-hop-interface *interface* [ disable | distance ]

#### **Parameters**

#### static

A static route in an alternate routing table.

table table

Multi-node. An alternate routing table to be used by policy-based routing rules.

interface-route subnet

Multi-node. An interface-based static route. The format is a destination subnet of the form *address/prefix* (*x.x.x.xlx*).

You can define multiple interface-based routes by creating multiple **interface-route** configuration nodes.

next-hop-interface interface

The next-hop interface.

disable

Disables the interface-based static route.

distance distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance. The distance ranges from 1 through 255. The default distance is 1.

#### Modes

#### Configuration mode

#### Configuration Statement

#### **Usage Guidelines**

Use this command to configure interface-based static routes in an alternate routing table. The alternate routing tables are used with policy-based routing. Refer to *Brocade 5600 vRouter Policy-based Routing Reference Guide* for information on policy-based routing.

Use the set form of this command to configure a next-hop interface.

Use the **delete** form of this command to remove a next-hop interface.

Use the **show** form of this command to view a next-hop interface.

### protocols static table route <subnet> blackhole <distance>

Configures a a black hole static route in an alternate routing table.

Syntax

set protocols static table table route subnet blackhole [ distance distance ]

delete protocols static table table route subnet blackhole [ distance ]

show protocols static table table route subnet blackhole [ distance ]

**Parameters** 

table table

Multi-node. An alternate routing table to be used by policy-based routing rules.

route subnet

Multi-node. Defines a static route. The format is a destination subnet of the form address/prefix (x.x.x.x/x).

You can define multiple static routes by creating multiple **route** configuration nodes.

distance distance

The black hole distance for this route. Routes with a smaller distance are selected before those with a larger distance. The distance ranges from 1 through 255. The default distance is 1.

#### Modes

Configuration mode

#### Configuration Statement

#### **Usage Guidelines**

Use this command to configure a black hole static route in an alternate policy route table. A black hole route is a route for which the system silently discards packets that are matched.

The alternate routing tables are used with policy-based routing. Refer to *Brocade 5600 vRouter Policy-based Routing Reference Guide* for information on policy-based routing.

Use the **set** form of this command to configure a black hole static route.

Use the **delete** form of this command to remove a black hole static route.

Use the **show** form of this command to view a black hole static route.

### protocols static table route <subnet> next-hop <address>

Configures the next hop for a static route in an alternate routing table.

**Syntax** 

set protocols static table table route subnet next-hop address [ disable | distance distance ]

delete protocols static table table route subnet next-hop address [ disable | distance [ distance ] ]

show protocols static table table route subnet next-hop address [ disable | distance [ distance ] ]

**Parameters** 

table table

Multi-node. An alternate routing table to be used by policy-based routing rules.

route subnet

Multi-node. Defines a static route. The format is a destination subnet of the form address/prefix (x.x.x.x/x).

You can define multiple static routes by creating multiple **route** configuration nodes.

next-hop address

The address of the next-hop router.

disable

Disables the static route.

distance distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance. The distance ranges from 1 through 255. The default distance is 1.

Modes

Configuration mode

#### Configuration Statement

#### **Usage Guidelines**

Use this command to configure static routes in an alternate routing table. The alternate routing tables are used with policy-based routing. Refer to *Brocade 5600 vRouter Policy-based Routing Reference Guide* for information on policy-based routing.

Use the **set** form of this command to configure the next hop for a route in an alternate routing table.

Use the **delete** form of this command to remove the next hop from a static route in an alternate routing table.

Use the **show** form of this command to view the next hop for a static route in an alternate routing table.

### protocols static table route6 <subnet> next-hop <address>

Configures the next hop for an IPv6 static route in an alternate routing table.

Syntax

set protocols static table table route6 subnet next-hop address [ disable | distance distance ]

delete protocols static table table route6 subnet next-hop address [ disable | distance ]

show protocols static table table route6 subnet next-hop address [ disable | distance ]

**Parameters** 

table table

Multi-node. An alternate routing table to be used by policy-based routing rules.

route6 subnet

Multi-node. An IPv6 static route. The format is a destination subnet of the form IPv6- address/prefix (h:h:h:h:h:h:h:h)x).

You can define multiple static routes by creating multiple **route6** configuration nodes.

disable

Disables the IPv6 static route.

distance distance

The next-hop distance for this route. Routes with a smaller distance are selected before those with a larger distance.

Modes

Configuration mode

#### Configuration Statement

#### **Usage Guidelines**

Use this command to configure IPv6 static routes on the system in an alternate routing table. The alternate routing tables are used with policy-based routing. Refer to *Brocade 5600 vRouter Policy-based Routing Reference Guide* for information on policy-based routing.

Use the **set** form of this command to configure the next hop for an IPv6 static route in an alternate routing table.

Use the **delete** form of this command to remove the next hop for an IPv6 static route in an alternate routing table.

Use the **show** form of this command to view the next hop for an IPv6 static route in an alternate routing table.

### protocols static table route6 <subnet> blackhole [distance]

Configures a black hole static route in an alternate routing table.

Syntax set protocols static table table route6 subnet blackhole distance [ distance ]

delete protocols static table table route6 subnet blackhole distance

show protocols static table table route6 subnet blackhole distance

Parameters 1

table table

Multi-node. An alternate routing table to be used by policy-based routing rules.

route6 subnet

Multi-node. An IPv6 static route. The format is a destination subnet of the form

IPv6-address/prefix (h:h:h:h:h:h:h:h/x).

You can define multiple static routes by creating multiple route configuration

nodes.

blackhole

A destination router that is offline and cannot receive traffic or provide

messages to the source of the traffic.

distance distance

The black hole distance for this route. Routes with a smaller distance are selected before those with a larger distance.

Modes

Configuration mode

#### Configuration Statement

#### **Usage Guidelines**

Use this command to configure a black hole IPv6 static route in an alternate routing table. A black hole route silently discards packets that are matched.

The alternate routing tables are used with policy-based routing. Refer to *Brocade 5600 vRouter Policy-based Routing Reference Guide* for information on policy-based routing.

Use the **set** form of this command to configure a black hole IPv6 static route.

Use the **delete** form of this command to remove a black hole IPv6 static route.

Use the **show** form of this command to view a black hole IPv6 static route.

### **Source Routes**


### Source routing example

Figure 3 shows a simple site using PBR on the Brocade vRouter (R1) to route traffic from two different internal subnets to two Internet links.

In this example:

- All Internet-bound traffic from subnet 192.168.10.0/24 is routed out interface dp0p0p1.
- All Internet-bound traffic from subnet 192.168.20.0/24 is routed out interface dp0p0p2.

#### FIGURE 3 Source routing using PBR



To configure this scenario, perform the following steps in configuration mode.

**TABLE 8** Source routing using PBR

Step	Command
Create the SRC-ROUTE policy.	vyatta@R1# set policy route pbr SRC-ROUTE
Create rule 10 and specify the destination address to match. In this case, any destination address will match.	<pre>vyatta@R1# set policy route pbr SRC-ROUTE rule 10 destination address 0.0.0.0/0</pre>

158

 TABLE 8
 Source routing using PBR (Continued)

TABLE 6 Source routing using 1 bit (con	imada)
Specify the source address to match. In this case, any address on subnet 192.168.10.0/24 will match.	vyatta@Rl# set policy route pbr SRC-ROUTE rule 10 source address 192.168.10.0/24
Specify that all packets that match should use alternate routing table 1.	<pre>vyatta@R1# set policy route pbr SRC-ROUTE rule 10 set table 1</pre>
Create rule 20 and specify the destination address to match. In this case, any destination address will match.	<pre>vyatta@Rl# set policy route pbr SRC-ROUTE rule 20 destination address 0.0.0.0/0</pre>
Specify the source address to match. In this case, any address on subnet 192.168.20.0/24 will match.	vyatta@R1# set policy route pbr SRC-ROUTE rule 20 source address 192.168.20.0/24
Specify that all packets that match should use alternate routing table 2.	<pre>vyatta@R1# set policy route pbr SRC-ROUTE rule 20 set table 2</pre>
Commit the change.	vyatta@R1# commit
Show the policy-based routing configuration.	<pre>vyatta@Rl# show policy route SRC-ROUTE {     rule 10 {         destination {             address 0.0.0.0/0         }         set {                table 1         }         source {                address 192.168.10.0/24         }         rule 20 {             destination {                  address 0.0.0.0/0         }         set {                  table 2         }         source {                  address 192.168.20.0/24         } }</pre>
Create the alternative routing table 1 and route default traffic to the first Internet connection.	<pre>vyatta@R1# set protocols static table 1 route 0.0.0.0/0 nexthop 12.34.56.11</pre>
Create the alternative routing table 2 and route default traffic to the second Internet connection.	<pre>vyatta@R1# set protocols static table 2 route 0.0.0.0/0 nexthop 98.76.54.22</pre>
Commit the change.	vyatta@R1# commit

TABLE 8 Source routing using PBR (Continued)

```
Show the alternate routing table configuration.
                                             vyatta@R1# show protocols static
                                              table 1 {
                                                   route 0.0.0.0/0 {
                                                        next-hop 12.34.56.11 {
                                              table 2 {
                                                   route 0.0.0.0/0 {
                                                        next-hop 98.76.54.22 {
Assign an address to dp0p0p1.
                                             \label{eq:continuous} \begin{tabular}{ll} vyatta@R1\# set interfaces dataplane dp0p0p1 \\ address 12.34.56.33/24 \end{tabular}
Assign an address to dp0p0p2.
                                             vyatta@R1# set interfaces dataplane dp0p0p2
                                             address 98.76.54.44/24
Assign an address to dp0p0p3.
                                             vyatta@R1# set interfaces dataplane dp0p0p3
                                             address 192.168.10.254/24
Assign the policy to the interface connected to
                                            \label{eq:continuous} \mbox{vyatta@R1\# set interfaces dataplane dp0p0p3} \\ \mbox{policy route SRC-ROUTE}
subnet 192.168.10.0/24.
Assign an address to dp0p0p4.
                                            vyatta@R1# set interfaces dataplane dp0p0p4 address 192.168.20.254/24
Assign the policy to the interface connected to
                                             vyatta@R1# set interfaces dataplane dp0p0p4
subnet 192.168.20.0/24.
                                             policy route SRC-ROUTE
Commit the change.
                                             vyatta@R1# commit
Show the dataplane interface configuration.
                                             vyatta@R1# show interfaces dataplane
                                              dataplane dp0p0p1 {
                                                   address 12.34.56.33/24
                                                   duplex auto
                                                   hw-id 00:93:0b:23:ab:e1
                                                   speed auto
                                              dataplane dp0p0p2 {
                                                   address 98.76.54.44/24
                                                   duplex auto
                                                   hw-id 00:93:0b:23:ab:e2
                                                   speed auto
                                              dataplane dp0p0p3 {
                                                   address 192.168.10.254/24
                                                   duplex auto
                                                   hw-id 00:93:0b:23:ab:e3
                                                   policy {
                                                        route SRC-ROUTE
                                                   speed auto
                                              dataplane dp0p0p4 {
                                                   address 192.168.20.254/24
                                                   duplex auto
                                                   hw-id 00:93:0b:23:ab:e4
                                                   policy {
                                                        route SRC-ROUTE
                                                   speed auto
```

Source routing example

## **List of Acronyms**

ACL	access control list
ADSL	Asymmetric Digital Subscriber Line
АН	Authentication Header
AMI	Amazon Machine Image
API	Application Programming Interface
AS	autonomous system
ARP	Address Resolution Protocol
AWS	Amazon Web Services
BGP	Border Gateway Protocol
BIOS	Basic Input Output System
BPDU	Bridge Protocol Data Unit
CA	certificate authority
ССМР	AES in counter mode with CBC-MAC
CHAP	Challenge Handshake Authentication Protocol
CLI	command-line interface
DDNS	dynamic DNS
DHCP	Dynamic Host Configuration Protocol
DHCPv6	Dynamic Host Configuration Protocol version 6
DLCI	data-link connection identifier
DMI	desktop management interface
DMVPN	dynamic multipoint VPN
DMZ	demilitarized zone
DN	distinguished name
DNS	Domain Name System

DSCP	Differentiated Services Code Point
DSL	Digital Subscriber Line
eBGP	external BGP
EBS	Amazon Elastic Block Storage
EC2	Amazon Elastic Compute Cloud
EGP	Exterior Gateway Protocol
ECMP	equal-cost multipath
ESP	Encapsulating Security Payload
FIB	Forwarding Information Base
FTP	File Transfer Protocol
GRE	Generic Routing Encapsulation
HDLC	High-Level Data Link Control
I/O	Input/Output
ICMP	Internet Control Message Protocol
IDS	Intrusion Detection System
IEEE	Institute of Electrical and Electronics Engineers
IGMP	Internet Group Management Protocol
IGP	Interior Gateway Protocol
IPS	Intrusion Protection System
IKE	Internet Key Exchange
IP	Internet Protocol
IPOA	IP over ATM
IPsec	IP Security
IPv4	IP Version 4
IPv6	IP Version 6
ISAKMP	Internet Security Association and Key Management Protocol
ISM	Internet Standard Multicast

ISP	Internet Service Provider
KVM	Kernel-Based Virtual Machine
L2TP	Layer 2 Tunneling Protocol
LACP	Link Aggregation Control Protocol
LAN	local area network
LDAP	Lightweight Directory Access Protocol
LLDP	Link Layer Discovery Protocol
MAC	medium access control
mGRE	multipoint GRE
MIB	Management Information Base
MLD	Multicast Listener Discovery
MLPPP	multilink PPP
MRRU	maximum received reconstructed unit
мти	maximum transmission unit
NAT	Network Address Translation
NBMA	Non-Broadcast Multi-Access
ND	Neighbor Discovery
NHRP	Next Hop Resolution Protocol
NIC	network interface card
NTP	Network Time Protocol
OSPF	Open Shortest Path First
OSPFv2	OSPF Version 2
OSPFv3	OSPF Version 3
PAM	Pluggable Authentication Module
PAP	Password Authentication Protocol
PAT	Port Address Translation
PCI	peripheral component interconnect

PIM	Protocol Independent Multicast
PIM-DM	PIM Dense Mode
PIM-SM	PIM Sparse Mode
PKI	Public Key Infrastructure
PPP	Point-to-Point Protocol
PPPoA	PPP over ATM
PPPoE	PPP over Ethernet
PPTP	Point-to-Point Tunneling Protocol
PTMU	Path Maximum Transfer Unit
PVC	permanent virtual circuit
QoS	quality of service
RADIUS	Remote Authentication Dial-In User Service
RHEL	Red Hat Enterprise Linux
RIB	Routing Information Base
RIP	Routing Information Protocol
RIPng	RIP next generation
RP	Rendezvous Point
RPF	Reverse Path Forwarding
RSA	Rivest, Shamir, and Adleman
Rx	receive
S3	Amazon Simple Storage Service
SLAAC	Stateless Address Auto-Configuration
SNMP	Simple Network Management Protocol
SMTP	Simple Mail Transfer Protocol
SONET	Synchronous Optical Network
SPT	Shortest Path Tree
SSH	Secure Shell

SSID	Service Set Identifier
SSM	Source-Specific Multicast
STP	Spanning Tree Protocol
TACACS+	Terminal Access Controller Access Control System Plus
TBF	Token Bucket Filter
TCP	Transmission Control Protocol
TKIP	Temporal Key Integrity Protocol
ToS	Type of Service
TSS	TCP Maximum Segment Size
Tx	transmit
UDP	User Datagram Protocol
VHD	virtual hard disk
vif	virtual interface
VLAN	virtual LAN
VPC	Amazon virtual private cloud
VPN	virtual private network
VRRP	Virtual Router Redundancy Protocol
WAN	wide area network
WAP	wireless access point
WPA	Wired Protected Access

List of Acronyms

166